

# Ransburg MicroPak 2e Controls



Model: A13338

**IMPORTANT:** Before using this equipment, carefully read SAFETY PRECAUTIONS, starting on page 5, and all instructions in this manual. Keep this Service Manual for future reference.

**NOTE:** This manual has been changed from revision **LN-9624-00.2** to revision **LN-9624-00-R3**. Reasons for this change are noted under “Manual Change Summary” inside the back cover of this manual.

# CONTENTS

<b>SAFETY:</b>	<b>5-9</b>
<a href="#">Safety Precautions</a> .....	5
<a href="#">Hazards / Safegaurds</a> .....	6
 <b>HV CONTROLLER</b>	
<b>HV CONTROLLER - INTRODUCTION:</b>	<b>10-15</b>
<a href="#">General Description</a> .....	11
<a href="#">Safety Features</a> .....	11
<a href="#">Displays</a> .....	11
<a href="#">Specifications</a> .....	12
<a href="#">Password Protections</a> .....	13
<a href="#">Operator Interface</a> .....	14
<a href="#">Switches</a> .....	14
<a href="#">LED's</a> .....	14
<a href="#">Buttons</a> .....	15
 <b>HV CONTROLLER - INSTALLATION:</b>	<b>16-22</b>
<a href="#">General Information</a> .....	16
<a href="#">Location of Product</a> .....	16
<a href="#">Mounting</a> .....	16
<a href="#">Input Power Connections</a> .....	16
<a href="#">Ethernet Connections</a> .....	17
<a href="#">Output to Cascade</a> .....	18
<a href="#">Electrical Noise</a> .....	18
<a href="#">Interlock Connections</a> .....	22
 <b>HV CONTROLLER - OPERATION:</b>	<b>23-42</b>
<a href="#">Start-Up</a> .....	23
<a href="#">Software Mismatch Fault</a> .....	23
<a href="#">Start-Up Menu</a> .....	24
<a href="#">Menus and Operation</a> .....	25
<a href="#">Run Menus</a> .....	26
<a href="#">Configuration Menus</a> .....	27
<a href="#">Configuration Parameters and Settings</a> .....	31
<a href="#">Diagnostics Menu</a> .....	32
<a href="#">Operating Parameters and Settings</a> .....	33
<a href="#">Control Conditions</a> .....	36
<a href="#">System Status (STS)</a> .....	36
<a href="#">System Check (CHK)</a> .....	36
<a href="#">System Fault Behavior</a> .....	36
<a href="#">Ethernet/IP Interface</a> .....	37

(Continued On Next Page)

# CONTENTS (Cont.)

## ATOMIZER CONTROLLER

<b>ATOMIZER CONTROLLER - INTRODUCTION:</b>	<b>43-47</b>
<a href="#">Atomizer Controller General Description</a> .....	44
<a href="#">Specifications</a> .....	44
<a href="#">Speed Control</a> .....	46
<b>ATOMIZER CONTROLLER - OPERATION:</b>	<b>48-57</b>
<a href="#">Operation</a> .....	48
<a href="#">Configuration Menus</a> .....	48
<a href="#">Configuration Parameters and Settings</a> .....	49
<a href="#">Operating Parameters and Settings</a> .....	49
<a href="#">Automatic Shutdown</a> .....	50
<a href="#">Interfacing Considerations</a> .....	51
<a href="#">User Defined I-O's</a> .....	51
<a href="#">Ethernet/IP Interface</a> .....	51

## DISCRETE IO CONTROLLER

<b>DISCRETE IO CONTROLLER - INTRODUCTION:</b>	<b>58-60</b>
<a href="#">Discrete IO Controller General Description</a> .....	59
<a href="#">Specifications</a> .....	59
<a href="#">Configuration Parameters and Settings</a> .....	60
<b>DISCRETE IO CONTROLLER - OPERATION:</b>	<b>61-62</b>
<a href="#">Operations</a> .....	61
<a href="#">Discrete I/O Controller Logic Relating to Inputs on Connector J5</a> .....	62

## MicroPak 2e CONTROLS

<b>INTEGRATION NOTES:</b>	<b>63-65</b>
<a href="#">Guidelines</a> .....	63
<a href="#">High Voltage Controller Logic Relating to Inputs On Connector J5</a> .....	65
<b>MAINTENANCE:</b>	<b>66-67</b>
<a href="#">Troubleshooting Guide</a> .....	66
<b>PARTS IDENTIFICATION:</b>	<b>68</b>
<a href="#">MicroPak 2e High Voltage Controller - Parts List</a> .....	68
<b>APPENDIX:</b>	<b>69-72</b>
<a href="#">MicroPak 2e Controller Panel Mount Layout</a> .....	69
<a href="#">MicroPak 2e Controller/MultiFunction IO Layout</a> .....	70
<a href="#">Initialization Screens</a> .....	71
<b>MANUAL CHANGE SUMMARY:</b>	<b>73</b>
<a href="#">Manual Changes</a> .....	73

# SAFETY

## SAFETY PRECAUTIONS

Before operating, maintaining or servicing any Ransburg electrostatic coating system, read and understand all of the technical and safety literature for your Ransburg products. This manual contains information that is important for you to know and understand. This information relates to **USER SAFETY** and **PREVENTING EQUIPMENT PROBLEMS**. To help you recognize this information, we use the following symbols. Please pay particular attention to these sections.

### **WARNING**

A **WARNING!** states information to alert you to a situation that might cause serious injury if instructions are not followed.

### **CAUTION**

A **CAUTION!** states information that tells how to prevent damage to equipment or how to avoid a situation that might cause minor injury.

### **NOTE**

A **NOTE** is information relevant to the procedure in progress.

While this manual lists standard specifications and service procedures, some minor deviations may be found between this literature and your equipment. Differences in local codes and plant requirements, material delivery requirements, etc., make such variations inevitable. Compare this manual with your system installation drawings and appropriate Ransburg equipment manuals to reconcile such differences.


Careful study and continued use of this manual will provide a better understanding of the equipment and process, resulting in more efficient operation, longer trouble-free service and faster, easier troubleshooting. If you do not have the manuals and safety literature for your Ransburg system, contact your local Ransburg representative or Ransburg.



### **WARNING**


- The user **MUST** read and be familiar with the Safety Section in this manual and the Ransburg safety literature therein identified.
- This equipment is intended to be used by trained personnel **ONLY**.
- This manual **MUST** be read and thoroughly understood by **ALL** personnel who operate, clean or maintain this equipment! Special care should be taken to ensure that the **WARNINGS** and safety requirements for operating and servicing the equipment are followed. The user should be aware of and adhere to **ALL** local building and fire codes and ordinances as well as **NFPA-33 AND EN 50176 SAFETY STANDARDS, LATEST EDITION**, or applicable country safety standards, prior to installing, operating, and/or servicing this equipment.

### **WARNING**




- The hazards shown on the following pages may occur during the normal use of this equipment. Please read the hazard chart beginning on page 2.

<p><b>AREA</b> Tells where hazards may occur.</p>	<p><b>HAZARD</b> Tells what the hazard is.</p>	<p><b>SAFEGUARDS</b> Tells how to avoid the hazard.</p>
<p><b>Spray Area</b></p> 	<p><b>Fire Hazard</b></p> <p>Improper or inadequate operation and maintenance procedures will cause a fire hazard.</p> <p>Protection against inadvertent arcing that is capable of causing fire or explosion is lost if any safety interlocks are disabled during operation. Frequent Power Supply or Controller shutdown indicates a problem in the system requiring correction.</p>	<p>Fire extinguishing equipment must be present in the spray area and tested periodically.</p> <p>Spray areas must be kept clean to prevent the accumulation of combustible residues.</p> <p>Smoking must never be allowed in the spray area.</p> <p>The high voltage supplied to the atomizer must be turned off prior to cleaning, flushing or maintenance.</p> <p>Spray booth ventilation must be kept at the rates required by NFPA-33, OSHA, country, and local codes. In addition, ventilation must be maintained during cleaning operations using flammable or combustible solvents.</p> <p>Electrostatic arcing must be prevented. Safe sparking distance must be maintained between the parts being coated and the applicator. A distance of 1 inch for every 10KV of output voltage is required at all times.</p> <p>Test only in areas free of combustible material. Testing may require high voltage to be on, but only as instructed.</p> <p>Non-factory replacement parts or unauthorized equipment modifications may cause fire or injury. If used, the key switch bypass is intended for use only during setup operations. Production should never be done with safety interlocks disabled.</p> <p>The paint process and equipment should be set up and operated in accordance with NFPA-33, NEC, OSHA, local, country, and European Health and Safety Norms.</p>

<p><b>AREA</b> Tells where hazards may occur.</p>	<p><b>HAZARD</b> Tells what the hazard is.</p>	<p><b>SAFEGUARDS</b> Tells how to avoid the hazard.</p>
<p><b>Spray Area</b></p> 	<p><b>Explosion Hazard</b></p> <p>Improper or inadequate operation and maintenance procedures will cause a fire hazard.</p> <p>Protection against inadvertent arcing that is capable of causing fire or explosion is lost if any safety interlocks are disabled during operation.</p> <p>Frequent Power Supply or Controller shutdown indicates a problem in the system requiring correction.</p>	<p>Electrostatic arcing must be prevented. Safe sparking distance must be maintained between the parts being coated and the applicator. A distance of 1 inch for every 10KV of output voltage is required at all times.</p> <p>Unless specifically approved for use in hazardous locations, all electrical equipment must be located <b>outside</b> Class I or II, Division 1 or 2 hazardous areas, in accordance with NFPA-33.</p> <p>Test only in areas free of flammable or combustible materials.</p> <p>The current overload sensitivity (if equipped) <b>MUST</b> be set as described in the corresponding section of the equipment manual. Protection against inadvertent arcing that is capable of causing fire or explosion is lost if the current overload sensitivity is not properly set. Frequent power supply shutdown indicates a problem in the system which requires correction.</p> <p>Always turn the control panel power off prior to flushing, cleaning, or working on spray system equipment.</p> <p>Before turning high voltage on, make sure no objects are within the safe sparking distance.</p> <p>Ensure that the control panel is interlocked with the ventilation system and conveyor in accordance with NFPA-33, EN 50176.</p> <p>Have fire extinguishing equipment readily available and tested periodically.</p>
<p><b>General Use and Maintenance</b></p> 	<p>Improper operation or maintenance may create a hazard.</p> <p>Personnel must be properly trained in the use of this equipment.</p>	<p>Personnel must be given training in accordance with the requirements of NFPA-33, EN 60079-0.</p> <p>Instructions and safety precautions must be read and understood prior to using this equipment.</p> <p>Comply with appropriate local, state, and national codes governing ventilation, fire protection, operation maintenance, and housekeeping. Reference OSHA, NFPA-33, EN Norms and your insurance company requirements.</p>

<b>AREA</b> Tells where hazards may occur.	<b>HAZARD</b> Tells what the hazard is.	<b>SAFEGUARDS</b> Tells how to avoid the hazard.
<p><b>Spray Area / High Voltage Equipment</b></p> 	<p><b>Electrical Discharge</b></p> <p>There is a high voltage device that can induce an electrical charge on ungrounded objects which is capable of igniting coating materials.</p> <p>Inadequate grounding will cause a spark hazard. A spark can ignite many coating materials and cause a fire or explosion.</p>	<p>Parts being sprayed and operators in the spray area must be properly grounded.</p> <p>Parts being sprayed must be supported on conveyors or hangers that are properly grounded. The resistance between the part and earth ground must not exceed 1 meg ohm. (Refer to NFPA-33.)</p> <p>Operators must be grounded. Rubber soled insulating shoes should not be worn. Grounding straps on wrists or legs may be used to assure adequate ground contact.</p> <p>Operators must not be wearing or carrying any ungrounded metal objects.</p> <p>When using an electrostatic handgun, operators must assure contact with the handle of the applicator via conductive gloves or gloves with the palm section cut out.</p> <p><b>NOTE: REFER TO NFPA-33 OR SPECIFIC COUNTRY SAFETY CODES REGARDING PROPER OPERATOR GROUNDING.</b></p> <p>All electrically conductive objects in the spray area, with the exception of those objects required by the process to be at high voltage, must be grounded. Grounded conductive flooring must be provided in the spray area.</p> <p>Always turn off the power supply prior to flushing, cleaning, or working on spray system equipment.</p> <p>Unless specifically approved for use in hazardous locations, all electrical equipment must be located <b>outside</b> Class I or II, Division 1 or 2 hazardous areas, in accordance with NFPA-33.</p> <p>Avoid installing an applicator into a fluid system where the solvent supply is ungrounded.</p> <p>Do not touch the applicator electrode while it is energized.</p>



<p><b>AREA</b> Tells where hazards may occur.</p>	<p><b>HAZARD</b> Tells what the hazard is.</p>	<p><b>SAFEGUARDS</b> Tells how to avoid the hazard.</p>
<p><b>Electrical Equipment</b></p> 	<p><b>Electrical Discharge</b></p> <p>High voltage equipment is utilized in the process. Arcing in the vicinity of flammable or combustible materials may occur. Personnel are exposed to high voltage during operation and maintenance.</p> <p>Protection against inadvertent arcing that may cause a fire or explosion is lost if safety circuits are disabled during operation.</p> <p>Frequent power supply shut-down indicates a problem in the system which requires correction.</p> <p>An electrical arc can ignite coating materials and cause a fire or explosion.</p>	<p>Unless specifically approved for use in hazardous locations, the power supply, control cabinet, and all other electrical equipment must be located outside Class I or II, Division 1 and 2 hazardous areas in accordance with NFPA-33 and EN 50176.</p> <p>Turn the power supply OFF before working on the equipment.</p> <p>Test only in areas free of flammable or combustible material.</p> <p>Testing may require high voltage to be on, but only as instructed.</p> <p>Production should never be done with the safety circuits disabled.</p> <p>Before turning the high voltage on, make sure no objects are within the sparking distance.</p>
<p><b>Toxic Substances</b></p> 	<p><b>Chemical Hazard</b></p> <p>Certain materials may be harmful if inhaled, or if there is contact with the skin.</p>	<p>Follow the requirements of the Safety Data Sheet supplied by coating material manufacturer.</p> <p>Adequate exhaust must be provided to keep the air free of accumulations of toxic materials.</p> <p>Use a mask or respirator whenever there is a chance of inhaling sprayed materials. The mask must be compatible with the material being sprayed and its concentration. Equipment must be as prescribed by an industrial hygienist or safety expert, and be NIOSH approved.</p>
<p><b>Spray Area</b></p> 	<p><b>Explosion Hazard — Incompatible Materials</b></p> <p>Halogenated hydrocarbon solvents for example: methylene chloride and 1,1,1,-Trichloroethane are not chemically compatible with the aluminum that might be used in many system components. The chemical reaction caused by these solvents reacting with aluminum can become violent and lead to an equipment explosion.</p>	<p>Spray applicators require that aluminum inlet fittings be replaced with stainless steel.</p> <p>Aluminum is widely used in other spray application equipment - such as material pumps, regulators, triggering valves, etc. Halogenated hydrocarbon solvents must never be used with aluminum equipment during spraying, flushing, or cleaning. Read the label or data sheet for the material you intend to spray. If in doubt as to whether or not a coating or cleaning material is compatible, contact your coating supplier. Any other type of solvent may be used with aluminum equipment.</p>

# Ransburg HV Controller



# HV Controller - INTRODUCTION

## GENERAL DESCRIPTION

The Ransburg MicroPak 2e (A13338-00), in conjunction with an appropriate cascade is used to provide high voltage for electrostatic application equipment. The controller is packaged in a single package measuring 5.1" tall X 8.5" wide X 6.5" deep (12.9cm tall x 21.6cm wide x 16.5cm deep). The controller can operate in "Local" and "Remote" conditions with either "Voltage Mode" or "Current Mode" of high voltage control.

The Ransburg MicroPak 2e Controller uses a combination of proven high voltage generation technology including microprocessor-based control with diagnostic and communication functions. It uses a variable voltage output to drive a cascade that amplifies the voltage to a high value. It also uses both current and voltage feedback information to maintain the desired set point. The processor circuitry provides the maximum in applicator transfer efficiency, while maintaining the maximum safety


The MicroPak 2e also supports the use of Multifunction I/O Controllers (MIO) to provide additional functions. Currently two add-on controller versions are supported: 1) an Atomizer Controller and 2) a Discrete IO Interface.

## SAFETY FEATURES

When used with the appropriate applicators and cascades, the Ransburg MicroPak 2e Controller provides the ultimate in operational safety. The protections include Overvoltage, Overcurrent and Di/Dt or Dv/Dt which are detailed in the Operating Parameters and Settings section of this manual. The micro-processor circuits allow the use of output load curve control, which limits the high voltage output to safe levels when the controls are set responsibly and safe distances are observed and followed.

## DISPLAYS

The front panel displays the high voltage and current output from the cascade as true readings. They are derived from feedback signals in the low voltage cable between the controller and the cascade.



MicroPak 2e Controller

## SPECIFICATIONS (At Sea-Level Conditions)

### Environmental/Physical

<b>Operating Temperature:</b>	0°C to +55°C
<b>Storage &amp; Shipping Temp.:</b>	-40°C to +85°C
<b>Humidity:</b>	95% Non-Condensing
<b>Physical Size:</b>	5.1" tall X 8.5" wide X 6.5" deep (12.9cm tall x 21.6cm wide x 16.5cm deep)

### Environmental Requirements

#### Power Required: (per controller)

<b>J11 - Controller :</b>	24V DC @ 0.5 Amps
<b>J4 - Cascade:</b>	24V DC @ 6.0 Amps (fully loaded output), RansPak 1000 (RP1000 or LEPS5002) Cascade 24V DC @ 2.0 Amps (fully loaded output), HP404, RP404, HP505 and CONSOLIDATED Cascades

**Note:** 24V DC power supply must be regulated and have over current and over voltage protection.

### Electrical

#### Controls:

<b>High Voltage Power:</b>	24 Volts, 10Amp, Form C relay contact
<b>Discrete In:</b>	(0-24 V) Remote Stop, Misc IO Interlock/Trigger, Door Interlock, Booth Air Interlock, (Analog) KV Setpoint (0-10V)
<b>Discrete Out:</b>	(3, Dry Contacts) Interlock Out, External Power Enable, System Alarm

**Controller Operating Range High Voltage:** 0-100kV, settable in 1kV increments

#### Current:

HP404/RP404	0-125 microamps
CONSOLIDATED	0-150 microamps
HP505	0-240 microamps
RP1000	0-1000 microamps
LEPS5002	0-1000 microamps

**Network Interface:** Ethernet/IP (Implicit Messaging only)

**Note:** A unique MAC address is hard coded into each MicroPak 2e & Atomizer Controller. User controls must be configured to recognize each unique address.

**Internal Controller Scan Time:** 1 msec (all data is taken from a rolling average of 16 scans)

### HP404 / RP404 Cascades

**Output:** 100 kV @ 0  $\mu$ A 125  $\mu$ A @ 0 kV  
In ATEX configuration: 90  $\mu$ A max current limit  
In FM configuration: 90  $\mu$ A max current limit 90 kV max voltage limit

**Cascade Size:** HP404 1.50" X 1.56" x 7.0" (38mm x 40mm x 178mm)  
RP404 4" X 4" X 12" (102mm x 102mm x 305mm)

### RP1000 / LEPS5002 Cascades

**Output:** 100 kV @ 0  $\mu$ A 1000  $\mu$ A @ 0 kV

**Cascade Size:** RP1000 4" X 4" X 12" (102mm x 102mm x 305mm)  
LEPS5002 17"x13"x13" (43cm x 33cm x 33cm)

*(Continued on next page)*

## SPECIFICATIONS (At Sea-Level Conditions) (Cont.)

### HP505 Cascade

Output:	100 kV @ 0 μA 240 μA @ 0 kV
Cascade Size:	1.50" X 1.56" x 7.0" (38mm x 40mm x 178mm)

### CONSOLIDATED Cascade

Output:	100 kV @ 0 μA 150 μA @ 0 kV
Cascade Sizes:	
A12760-02 (IN LINE):	3" X 3" x 16.97" (7.6cm x 7.6cm x 43.1cm)
A12761-02 (RIGHT ANGLE):	3" X 7.64" x 11.8" (7.6cm x 19.4cm x 30cm)

## PASSWORD PROTECTION

MicroPak 2e Controller parameters are password protected with three levels, Config, System and User to help prevent unqualified operators from changing the values. The password menu is composed of two screens. The first screen prompts the user to confirm they wish to enter the required password, while the second screen accepts the entry of the password digits. The three levels represent a hierarchy with Config at the top, System in the middle and User at the bottom. This means that while a higher level password is active, the user will not be required to enter a lower level password if they change a parameter which requires it.




Figure 1: System Password Screen

### User Password Menu

When the password has been entered, the user will be returned to the value being changed.




Figure 2: User Password Screen




Figure 3: Password Entry Screen

**NOTE**

➤ The MicroPak 2e controller is shipped with the following default passwords:  
**User - 7734    System - 7735**

It is recommended these be changed at installation by the customer, to prevent changes being made by anyone who has access to this manual.

## OPERATOR INTERFACE

The MicroPak 2e Controller shown in figure 4, has a physically simple operator interface consisting of five (5) LED's (Light Emitting Diodes), four (4) switches, seven (7) buttons, and two four line twenty character (4 X 20) alpha/numeric displays.




Figure 4: Operator Interface

## SWITCHES

### Power Switch

The rocker switch on the left and the LED directly above it are for power On/Off selection and display. The green LED is on when the power is On to the controller.

### Local / Remote Switch

This is a two position toggle switch used to determine if the Local (Front Panel) controls have priority or if the Remote controls (Ethernet/IP Connection or Discrete inputs) have priority. If the switch is up (Local Mode) the Front Panel controls may change parameters, enable or disable the high voltage, and clear faults. The Remote Ethernet/IP connection may look at parameters and values, but may not change them or enable/disable the high voltage output. If the switch is down (Remote Mode) the opposite is true except that the Front Panel switch may be changed to local Mode at any time to disable the Remote Controls and to enable the Local Controls.

Beginning with Software Version V1.1.00, when Ethernet/IP is enabled the MicroPak 2e maintains Local Mode parameters separate from the

Ethernet/IP parameters. This means that when switching between Local and Remote modes, operating parameters will typically change. Parameters which always change are the ones passed as variables in the Ethernet/IP Assemblies, e.g. KV Setpoint and Turbine Speed Setpoint. Parameters which are set indirectly using the Parameter Write function of the Assemblies, e.g. Max  $\mu$ A Limit, will use the Local Mode settings until they are changed through the Ethernet/IP interface. Once one of these parameters is changed using Ethernet/IP, the MicroPak 2e will toggle between the Local and Remote values at each mode change. This behavior will continue until the next power cycle of the controller.

### HV On / Off Switch

This is a return-to-center momentary toggle switch. It is active only when the Local/Remote mode switch is set to Local. It is used to enable and disable the High Voltage output and to clear system faults. When the System Checks and Current Status are OK, flipping the switch to the up position (HV On) will enable High Voltage Output (see "Figure 4 - Operator Interface" in this section). Flipping it to the down position (HV Off) will disable the High Voltage Output. If there is a system fault, flipping this switch to the OFF position (also known as the Reset position) will reset (clear) any faults currently detected by the system.

### Atomizer On / Off Switch

This is a two position toggle switch. It is used to enable and disable (i.e. start and stop) a configured atomizer when in LOCAL mode. When the controller is in REMOTE mode it is ignored.

## LED'S

### Power LED

If the Green Power LED is on, then the system power to the controller is On.

### HV Fault LED

The red HV Fault LED is lit when the system detects a fault condition (see "Figure 4 - Operator Interface" in the SWITCHES section). When operating in "Local Mode", it is cleared by flipping the HV On/Off switch to the OFF (Reset) position. If the system is still in a fault condition, it will immediately be lit as the system detects the fault.



### High Voltage LED

The green High Voltage LED displays the current state of the High Voltage Output. This LED is illuminated whenever High Voltage is being supplied.

### Atomizer Fault LED

The red Atomizer Fault LED is lit when the Atomizer subsystem detects a fault condition. This condition will be displayed on the Atomizer status screen.

### Atomizer LED

The green Atomizer LED is lit when the Atomizer controller commands the turbine to spin.

## BUTTONS

The seven buttons used to control the viewing and entry of information on the two 4 X 20 character displays are:

### HV/AT Button

The High Voltage/Atomizer Button (just below the right display) is used to toggle the active display between the "Atomizer" and "High Voltage" displays. Note that the active display always has a ■ (block character) in the lower right corner.

So when the High Voltage is the active display, it will look like "Figure 3 - 2nd Password Screen" in the PASSWORD PROTECTION section.

### Screen Button

The Screen Button (just below the right display) is used to change (toggle) to the next Menu screen. The menu screens wrap around so that after the last screen it will return to the first screen.

### Up and Down Buttons

The buttons above and below the Set Button in the middle (the Up and Down Buttons) are used to move the selection indicator vertically to a value to be selected by the Set Button. When in a value entry menu, the Up and Down buttons are used to increase or decrease the value being entered.

### Set Button

This labeled button (in the middle) is used to select the value to change and to enter the change after it has been made.

### Left and Right Buttons

The buttons to the right and left of the Set Button (the Left and Right Buttons) are used to move the selection horizontally.




Figure 5: Buttons

# HV Controller - INSTALLATION

## GENERAL INFORMATION

### WARNING

- The MicroPak 2e Controller **MUST** be located outside of the hazardous area.
- The User **MUST** read and be familiar with the “Safety” section of this manual.
- The User **MUST** set SAFE values for Max  $\mu$ A Limit, Di/Dt Mode and Di/Dt Sensitivity based on the operating environment. The controller ships with these values set to zero, which forces the user to complete an initialization sequence before the unit will function. See the appendix for details of the sequence.
- This manual **MUST** be read and thoroughly understood by ALL personnel who operate, clean, or maintain this equipment! Special care should be taken to ensure that the warnings and requirements of operating and servicing safely are followed. The user should be aware of and adhere to ALL local building and fire codes and ordinances as well as NFPA-33, OSHA, and all related country safety codes prior to installing, operating, and/or servicing this equipment.

### NOTE

- As each installation is unique, this information is intended to provide general installation information for the MicroPak 2e Controller. Consult your authorized Ransburg distributor or Ransburg Technical Service for specific directions pertaining to the installation of your equipment.

## LOCATION OF PRODUCT

Install the controller assembly in a control cabinet that is protected from the possibility of any contact with water, vapor or high humidity. Ambient temperature should not exceed 131°F (55°C). The area should be clean, dry and well ventilated.

### CAUTION

- **DO NOT** locate the Controller near or adjacent to heat producing equipment such as ovens, high wattage lamps, etc.




Figure 6: A13338 Control Module

## MOUNTING

Using eight (8) #4-40 or M3 screws (not included), secure the front panel of the MicroPak 2e & Atomizer Controller, using the supplied mounting holes, to enclosure. See Figure 46 in the appendix for a mounting diagram.

## INPUT POWER CONNECTIONS

Input power must be supplied from one or two regulated DC power supplies. Two connectors, J4 and J11 are provided so that controller operating power may be separated from cascade operating power. Cascade operating power is delivered through J4 and controller operating power is delivered through J11. This configuration gives the user



the ability to provide an ESTOP by inserting a suitable switch or contactor in the J4 power leads. When separate control of the cascade power is not required, power to J4 and J11 can be run from one DC power supply.

**⚠ CAUTION**

➤ Power supplies connected to J4 and J11 must be protected against excessive current and provide Over Voltage protection.

**NOTE**

➤ The Ransburg MicroPak 2e Controller has a built in resettable fuse in the controller power lead, so if the controller logic draws a current in excess of 1.5 amps it will open. Reset is achieved by turning controller power OFF for 5 minutes then back ON.




Figure 7: Input Power Connections




Figure 8: Ethernet Connector

Use the appropriate 10/100BASE-T Ethernet wiring (Straight EIA/TIA 568A) for your installation with an RJ-45 plug to connect to the MicroPak 2e Controller. Connection can be made using either J7 or J10 as shown in Figure 8 above.

TABLE 1		
Signal Name	J4 Connection	Power Supply
+VPWR	Pin 1	+ 24 VDC
+VPWR	Pin 2	+ 24 VDC
GND	Pin 3	DC return
GND	Pin 4	DC return
CHGND	Pin 5	Earth Ground

TABLE 2		
Signal Name	J11 Connection	Power Supply
+VPWR	Pin 1	+ 24 VDC
GND	Pin 2	DC return

Tables 1 & 2 show the connections for Cascade and Controller power.

**NOTE**

➤ The Ethernet connectors J7 and J10 use an integrated Ethernet Switch to connect to the controller. This allows the MicroPak 2e Controller to be networked with the LAN of a Robot or PLC and still provide a connection for a local networked display.

## OUTPUT TO CASCADE

Make connections from either J6 or J7 of the controller, depending on the cascade in use. Refer to Table 3 for J6 connections and Table 4 for J7 connections.




Figure 9: Outputs to Cascade

TABLE 3	
J6	Cascades A12760-02 / A12761-02
HVGND	Pin 1 0 VDC for R+ and E+ Power
VCT/R+	Pin 2 Analog DC Cascade Drive Signal
+15V/E+	Pin 3 Nominal 15 VDC for Cascade Electronics
SAFETY /GND	Pin 4 0 VDC for Analog Cascade Voltage Feedback
KVFB/ V-FB	Pin 5 Analog Cascade Voltage Feedback Signal
SHIELD/GND	Pin 6 0 VDC for Analog Cascade Current Feedback
μAFB/ I-FB	Pin 7 Analog Cascade Current Feedback Signal

TABLE 4	
J7	Cascades: HP404, RP404, HP505, RP1000, LEPS5002
HVGND	Pin 1 0 VDC for VCT Power
μAFB	Pin 2 Analog Cascade Current Feedback Signal
VCT	Pin 3 Analog DC Cascade Drive Signal
VCT	Pin 4 Analog DC Cascade Drive Signal
HP_DR B	Pin 5 High Power Cascade Drive Signal (HP404, HP505)
HP_DR A	Pin 6 High Power Cascade Drive Signal (HP404, HP505)
N.C.	Pin 7 (Termination point; No Connection)
N.C.	Pin 8 (Termination point; No Connection)
MULTI-GND	Pin 9 0 VDC for Analog Cascade Voltage Feedback
KVFB	Pin 10 Analog Cascade Voltage Feedback Signal
N.C.	Pin 11 (Termination point; No Connection)
HVGND	Pin 12 0 VDC for VCT Power
RP DR B	Pin 13 Logic Level Cascade Drive Signal (RP1000, LEPS5002)
RP DR A	Pin 14 Logic Level Cascade Drive Signal (RP1000, LEPS5002)
HVGND	Pin 15 0 VDC for VCT Power
HVGND	Pin 16 0 VDC for VCT Power

## ELECTRICAL NOISE

### MicroPak 2e Grounding

1. The Power Supply must be referenced to true earth ground at only one point, through the controller’s chassis ground connection. (Refer to Figures 10, 11, and 12 for Grounding Connections.)
2. Shields from the low voltage cable must be connected to the chassis ground where the controller’s ground connection is made, then by a 3/4” braid to the building steel or ground grid if available.

3. The low voltage cable has a large amount of high frequency noise on the shields and grounds from being in proximity to the high voltage generator. Taking these grounds directly to earth ground or a ground grid through good high frequency conductors (braid) keeps this high frequency noise from interfering with the low voltage control circuitry.
4. The feedback signals for kV and  $\mu\text{A}$  are developed with respect to the cascade ground signal (MULTIGND). If the cascade ground were routed only to earth ground via the above mentioned shields, the feedback conditioning circuitry would have to depend on the panel ground or power supply common to get a ground reference for the feedback signals. This means the low level return current for these signals would have to flow to earth ground and back to the controller via factory ground
- or power supply common. This adds large amounts of noise to these low voltage signals. To combat these effects, the controller PCB provides a connection for MULTIGND which is separately routed to the CHGND pin of J4. This is the single ground point for MULTIGND, HVGND and logic GND to minimize noise on the cascade feedback signals.
5. A great deal of testing under high voltage corona conditions has confirmed that this cascade ground should be connected directly at a single point to the signal ground plane of the MicroPak 2e power supply controller. This single point method maintains a "clean" feedback signal while limiting the amount of high frequency noise that is dumped onto the signal ground and therefore other grounds in the overall system, such as a PLC or robot.




Figure 10: MicroPak 2e Controller W/HP404, RP-404 & HP505 Cascade




Figure 11: MicroPak 2e Controller W/LEPS5002 or 74793 Cascade (RansPak 1000)




Figure 12: MicroPak 2e Controller W/CONSOLIDATED Cascade



## INTERLOCK CONNECTIONS




Figure 14: Interlock Connector

J5 is supplied to give the end-user access to interlock connections for integrating the controller into the user’s system. Three output signals are provided thru dry contacts (rated 30 VDC @ 2 amps maximum). These three signals indicate: 1) the state of controller operating power, 2) when a controller fault exists, and 3) the state of the controller interlock inputs. Four input signals are provided which should only be connected to dry contact outputs from the user’s system. The four interlock signals are designated as: 1) a door interlock, 2) a booth air interlock, which can be configured to serve as an HV Reset input, 3) a miscellaneous interlock, which can be configured to serve as a HV Trigger input, and 4) a remote stop input which removes power from the cascade drive circuits when sensed by the Display and Communications Processor. A fifth input which accepts a 0-10 VDC analog control signal is provided to allow control of the high voltage setpoint.

### NOTE

- The fourth interlock input Remote Stop cannot be disabled through software. If the user does not wish to use the Remote Stop input, a jumper must be placed between J5-13 and J5-14 to close the Remote Stop circuit.

Table 5 shows the pin assignments for the interlock signals.

TABLE 5 - J5 CONNECTOR SIGNALS

Outputs	
External Power Enable	Pin 1, 2
System Alarm Out	Pin 3, 4
Interlock Out	Pin 5, 6
Interlock Inputs	
Door Interlock (+)	Pin 7 *
Door Interlock (-)	Pin 8
Booth Air Interlock/ HV Reset (+)	Pin 9 *
Booth Air Interlock/ HV Reset (-)	Pin 10
Misc. Interlock/Trigger(+)	Pin 11 *
Misc. Interlock/Trigger(-)	Pin 12
Remote Stop (+)	Pin 13 *
Remote Stop (-)	Pin 14
Analog Inputs	
KV Setpoint (+)	Pin 15
KV Setpoint (Gnd)	Pin 16

\* Refer to the following note.

### NOTE

- The positive interlock input pins are directly connected to the internal +24VDC of the MP2e controller. It is recommended that these pins not be run outside of the MP2e enclosure without the addition of series limiting resistors (3.3K, 1/4w). This will prevent overloading the MP2e internal current limit if a positive input is accidentally shorted to ground. Alternatively, the user can provide a separate +24VDC supply external to the MP2e to power the (-) interlock inputs.



# HV Controller - OPERATION

## START-UP

Before its' first use, the following application specific features of the MicroPak 2e controller must be configured by the user. Refer to the appendix for 1<sup>st</sup> time initialization menus.

- The **Over Current Limit** (Max  $\mu$ A Limit) must be set to a value that is appropriate for the paint process being used.
- The **di/dt sensitivity** must be set to a value appropriate for the paint process being used.
- If the **Ethernet/IP interface** will be used, it must be enabled.
- If Ethernet/IP is being used, an **IP address** from the local network must be assigned.

### NOTE

- The following MicroPak 2e features are configured at the factory based on the system: 1) Cascade type, 2) If an Atomizer Controller is included, 3) Atomizer type included, 4) HV Charging Mode, 5) Control Mode, 6) If a Discrete IO Controller is included, 7) Cabinet type and 8) If Unilink support is included.

In addition, if MIO Controllers are present, the user must configure the type, i.e. voltage (0-10V) or current (4-20mA), of each signal being supplied to the analog inputs of the MIO controllers.

### NOTE

- For correct operation of the analog inputs, jumpers JMP9 to JMP15 on the MIO Controller must also be set to the matching V or I mode. See the sections on Atomizer or Discrete IO operation for further details.

## SOFTWARE MISMATCH FAULT

The Micropak 2e family of products incorporate multiple smart boards. These include:

- A13338-XXXXXXXXXX - Micropak 2e HV & Atomizer Controller. For replacement use, the user should order the same model number (-XXXXXXXXXX) listed on the original invoice. This module includes two separate boards:
  - A13239 - Display and Communications Processor.
  - A13240 - High Voltage Control Processor.
- A13245-X1 - Micropak 2e Multi-Function Board, "X" indicates quantity of A13248-00 Boards included.
- A13245-X8 - Micropak 2e Multi-Function Board, Discrete I/O configuration. "X" indicates quantity of A13248-00 boards included. (Note: currently there are no Single Bell Controller configurations which include this board).

Each of these boards has a processor and has software to run the board. For the MP2e system to be assured of operating correctly, the software version of each board must be at the same revision. When the system starts up, the boards communicate to each other. If the software versions do not match, a fault is set. This fault is displayed as "SwVer Mismatch". This fault cannot be cleared or bypassed.

**Under normal circumstances, this fault will never been seen** as all the boards are configured with the same version of software when shipped from the factory. This fault situation could occur if one of the boards is replaced with a new board that has a different version of software than the other boards in the system. It is important when purchasing replacement boards to ensure all boards in your MicroPak 2e have the same version of software.

### How To Tell What Version of Software is Loaded on a Micropak 2e System

When the Micropak 2e system is powered on, it will display the SW Version of the Display and Communications Processor board as noted in the image below. The picture is depicting an example of a system with software version 1.0.02.

**NOTE**

➤ If the front panel Local/Remote Switch is in the “Remote” position, this screen will only be displayed for two seconds before the system automatically goes to Run Mode and changes the screen.

**HIGH VOLTAGE**

```

DCP SW Ver: 1.1.15
HVC SW Ver: 1.1.15
MIO SW Ver: 1.1.15
    
```

Figure 14c: Software Versions of each Board

In the event of observing a SwVer Fault, call the Service Assistance number listed on the back cover for help getting the software loaded correctly.

**HIGH VOLTAGE**

```

Ransburg
SN 1434-0121      ©2014
Software Ver:    1.1.02
    
```

Figure 14a: Start-Up Menu Screen (Left)

**START-UP MENU**

The two menus that display on an initialized unit at power up are shown in Figures 15 and 16. The HIGH VOLTAGE screen displays the Serial Number, Copyright Date and Software Version of the unit.

Under normal circumstances, the other boards will match the Display and Communications Processor Board and there will be no fault reported. If the version of software on one of the other boards does not match the display board, a fault will be displayed. This indicates that software needs to be updated on one or more of the other boards. The following picture is an example showing the fault message.

**HIGH VOLTAGE**

```

Ransburg
SN 1330-0021      ©2015
Software Ver:    1.1.03
    
```

Figure 15: Start-Up Menu Screen (Left)

The ATOMIZER screen allows the user to select from one of three options: RUN mode, Configuration mode, or Diagnostics mode. In addition, the bottom line displays the status of the system connections.

**HIGH VOLTAGE**

```

Fault: SwVer Mismatch
Warn:  None

HVC EIP
    
```

Figure 14b: Start-Up Menu Screen (Left)

**NOTE**

➤ Starting with V1.1.07, an additional HIGH VOLTAGE screen has been added that will display the software versions of each board present in the system.

**ATOMIZER**

```

→Run←
Configuration
Diagnostics
HVC eip
    
```

Figure 16: Start-Up Menu Screen (Right)



The status is displayed via upper or lower case letters which indicate the associated board is communicating (upper case) or not communicating (lower case). The letters “HVC” represent the High Voltage Control board and “EIP” represents the Ethernet/IP host connection, When included in the system, “AT” represents an Atomizer Controller and “IO” represents a Discrete IO interface.

**NOTE**

► When the REMOTE/LOCAL switch is set to REMOTE at power-up, the controller automatically switches to RUN mode after approximately 5 seconds. When the REMOTE/LOCAL switch is set to LOCAL at power-up, the controller remains in the start-up screens until the user selects a mode. In software V1.1.02 and higher, if the user changes the REMOTE/LOCAL switch to REMOTE, the system immediately switches to RUN mode.

## MENUS AND OPERATION

On all of the menus, if a parameter can be changed it will be preceded by a blinking “→” and followed by a blinking “←” to show that it is a changeable value. If there is more than one changeable value on a screen, pressing the Up or Down and Left or Right Buttons will move the selection “→←”s to the next value. If there are no changeable values on a screen then the “Active Screen Indicator” in the lower right corner will blink. When the selection “→←”s surround the value you wish to change, press the Set Button. If the value to be changed requires a password, either the User, System or Config Password Menu will be displayed allowing you to enter the required password. After entering the Password, you are returned to the originally selected value. If the password was entered correctly, the value may now be changed. If the entry was incorrect, the password screen will again be displayed. Once a password has been successfully entered, it will remain active for a period of time that depends on the password type. It then times out and must be re-entered to make further changes. During the active time, the block character indicating the active screen will alternate with the letters U, S or C corresponding to entry of the User, System or Config password. The activated time period for these password types decreases as the privilege level increases (U = 4, S = 3 and C = 2 minutes).

When a numeric value is being changed, a value change menu, similar to the one shown in Figure 17, will be displayed. In this menu the Left and Right Buttons allow the user to select from the two methods available to change a value.




Figure 17: Value Change Screen

If the Inc/Dec method is selected, the user is shown the screen seen in Figure 18. In this mode, the Up and Down buttons (above and below the SET Button) can be used to incrementally change the value. The value will increase with the up button and decrease with the down button until it reaches the maximum or minimum allowed value.




Figure 18: Inc/Dec Change Mode Screen

If the Digit method is selected, the user is shown the screen seen in Figure 19. This shows the current value to be modified, the low and high limits for the selected parameter and the digit mode options to change the current value. The “-” option allows the user to negate the current value displayed. The “Null” option causes the current value to be cleared allowing the user to begin entry of a new value. The ‘number’ option (“→0←”) enables the Up and Down Buttons to select the next digit to be added to the value when the user presses the Set Button. The “Save” option saves any changes made in this screen and exits. And the “Quit” option cancels any changes made in the screen and exits.




Figure 19: Digit Mode Change Screen




Figure 21: Voltage Mode Screen

## RUN MENUS

### High Voltage Run Menu

This menu displays the KVSet value in Voltage Mode. Also displayed by this menu are the control mode and cascade type, the current actual KV value, the current  $\mu$ A value, the current hardware check value, the High Voltage status, and the current controller status. KVSet is the only changeable value on this menu. In Current Control Mode the menu displays  $\mu$ ASet as the changeable value instead of KVSet.




Figure 20: Run Menu Screen

### Voltage Mode Menu

The menu in Fig 21 is displayed when Voltage Control Mode is configured. It displays whether or not the DiDt feature is enabled and the sensitivity of this feature which is specified in units of  $\mu$ Amps per 100 milliseconds. If enabled, a fault occurs when the output current changes faster than the sensitivity value. The next element displayed on this screen is a user settable limit on cascade output current. This limit has a range of 0 to the maximum current for the currently configured cascade. It also provides an option to Save Changes to the parameter values. Selecting this option will cause the current values to be stored in flash memory, so that they will be available after a power cycle. If this option is not used, all parameter changes are discarded at the next power cycle when the saved parameters are restored. The first three values can be selected and changed.

### Current Mode Menu

The menu in Fig 22 is only displayed in Current Control Mode. It displays whether or not the DvDt feature is enabled and the sensitivity of this feature. If the voltage changes by more than this value in a 100 millisecond interval, a fault occurs. The last two items displayed are KV Low Limit and KV High Limit. These are used to set a lower and upper bound for the output voltage. If the bounds are exceeded a fault will occur. This menu also includes a Save Changes option so that modified values can be saved across power cycles.

### High Voltage Fault Menu




Figure 22: Current Mode Screen

This menu displays the latest fault and any current warning.




Figure 23: Fault Menu Screen

**Software Versions Menu**

Starting with V1.1.07, an additional HIGH VOLTAGE menu has been added that displays the software versions of each board present in the system. It is the next screen displayed if the user presses the “screen” button. (This is the ONLY place this screen can be accessed).




Figure 24: Software Versions of each Board

**Atomizer Run and Fault Menu**

When an atomizer is configured, this menu displays the configured atomizer type on line 1, followed by the Turbine Speed Set Point value and the current actual Turbine Speed value. In addition, the current Fault status of the Atomizer Controller and the current Bearing Air pressure are displayed. If no atomizer is configured, this screen shows the high voltage controller’s fault and connection status information similar to figure 23.




Figure 25: Run Menu Screen (Right)

**Automatic Gun Fault Menu**

This menu displays the latest faults for both the atomizer and high voltage controllers. In addition, it displays any current high voltage warning and the current connection status.




Figure 26: Gun Fault Menu Screen

**CONFIGURATION MENUS**

**High Voltage Controller Configuration Menus**

The following seven menus are displayed on the HIGH VOLTAGE screen (left panel).

**Cascade Menu**

This menu allows the factory to configure the type of cascade connected to the controller.




Figure 27: Cascade Menu Screen

Beginning in MP2e software version V1.1.10, a new configuration parameter, “Array Member”, has been added.

Some applications place multiple applicators close together. In some cases, the applicators may be close enough that one MP2e may detect voltage feedback which actually originates from an adjacent applicator as a fault condition. Turning all the near-by applicators on and off at the same time and at similar levels avoids most interaction issues. However, if near-by applicators are at very different output levels, the MP2e at the lower output level may detect a “Minimum Output” condition which should not be considered to be a fault condition.

When “Array Member” is set to “Enabled” (“Ena”), the MP2e will not declare a fault for a “Minimum Output” condition. “Disabled” is the default setting for “Array Member”. Reference Service Instruction SI-17-04 to access and change the “Array Member” configuration parameter.

**Interlock Menu**

The three Interlock inputs which can be enabled or disabled are configured in this screen. As seen in Figure 28, the first input is dedicated to use as an interlock and is labeled Door. The second interlock is labeled MiscIO. This input can serve as either an Interlock input or as a Trigger input. It is configured to the trigger function by selecting Interlock and pressing the Set button. It can similarly be returned to the interlock function by selecting Trigger and pressing the Set button. The third interlock is labeled Booth. This input can serve as either an Interlock input or as an HV Reset input. It is configured to the HV Reset function by selecting Interlock and pressing the Set button. It can similarly be returned to the interlock function by selecting HV Reset and pressing the Set button.

**NOTE**

- The system DEFAULTS to have all interlocks ENABLED. So if the interlocks are not wired closed, the controller will remain in a faulted condition.
- The fourth interlock input, Remote Stop, cannot be disabled. If the user does not wish to use the Remote Stop input, a jumper must be placed between J5-13 and J5-14 to close the Remote Stop circuit.
- When a Discrete IO Controller is configured or Ethernet/IP is enabled, the MiscIO and Booth inputs are forced to operate as Interlock inputs, i.e. the Trigger and HV Reset functions are not available.




Figure 28: Interlock Menu Screen

Beginning in MP2e software version V1.1.07, a new configuration parameter, "Remote Option", has been added. To determine which number (1-5) is the correct option for you, refer to the table shown below.

MP2e Remote Options			Configuration Options			System Options		
2016.05.12			(Factory Settings)			(Customer System Settings)		
(available after V1.1.06)			(Priority over Remote Options)			(Limited by Remote Option)		
Remote Option Number	Remote option name	Discription	SBC or CP (ControlPak)	Atomizer MIO - Enabled Or Disabled	Discrete MIO - Enabled or Disabled	EPI Enabled or Disabled	Misc IO - Disabled or Interlock Or Trigger	Booth - Disabled or Interlock or Reset
1	None	No Remote I/O enabled	SBC or CP	Dis or En	Dis	Dis	Dis or Int	Dis or Int
2	EIP	EIP Remote I/O enabled	SBC or CP	Dis or En	Dis	En	Dis or Int	Dis or Int
3	DIO	Discrete Remote I/O enabled	SBC or CP	En	En	Dis	Dis or Int	Dis or Int
4	HVC	HVC Remote I/O Enabled	SBC or CP	Dis	Dis	Dis	Trig	Reset
5	SBC HVCMO1	HVC and Some MIO I/O Enabled (requires additional SBC wiring)	SBC	En	Dis	Dis	Trig	Reset

The configuration options that have been set for your system at the factory will dictate the MP2e Remote Options that are available for you to choose from. In the Remote Options Table above, the “Configuration Options” columns with the purple header illuminate some of the questions that need to be answered before Remote Options are made available to you. These questions include:

1. Do you have a Single Bell Controller (SBC) or a Control Pak (CP)?
2. Do you have an Atomizer MIO Board configured as Enabled ?
3. Do you have a Discrete IO Board (DIO) configured as Enabled ?

Cell entries in the columns with the purple header show the acceptable answers to these questions for the Remote Option of interest.

Once you have identified which Remote Options are available to you based on your factory configuration, you may choose from among them according to the instructions found in steps 1-5 above. The Remote Option Parameter that you choose will be master to the other system settings shown in the Remote Options Filtering Table in the “System Options” columns with the green header. This ensures that related system parameters are set to compatible and consistent setting combinations. Cell entries in the columns with green headers show the settings that system options will be set to when corresponding Remote Options are chosen. In the instances where there are two options shown in one cell - for example: “Dis or Int” - you may use the methods described in the MP2e Service Manual (LN-9625-00) to choose how you would like these I/O signals configured.

If you enter a numeric value for the Remote Option Parameter that is not supported by your Factory Set Configuration as shown in the columns above with the purple header, your entry will not be accepted.

**MicroPak V-I Limiting Menu**

This menu displays four settings that the factory configures to match the product(s) purchased with the controller. These settings cannot be changed by the user.

The control mode indicates if the controller is set to control Voltage or Current. The Charge Type corresponds to how the high voltage charge is transferred to the material being

applied. This is normally set as direct for all cascades except the RP1000 when used with an indirect charge ring, The V-I limiting function is always enabled. It controls a software function which limits the voltage and current load curves to levels very similar to those used in the original MicroPak controller. The Cabinet Selection option is used to enable or disable use of the full complement of Atomizer IO signals. This is a factory configured setting.




Figure 29: MicroPak V-I Limiting Screen

**IP Address Menu**

This menu provides the user with four options. It allows setting the Ethernet/IP Address for the controller, provides control over whether Ethernet/IP communications are enabled or not, provides control over whether DHCP is used to acquire an IP address and allows the user to save any Configuration changes that have been made. Note that the Save or Quit options will place the unit into run mode. This is the only way to exit the Configuration Menus other than cycling controller power.




Figure 30: IP Address Menu Screen

When DHCP is disabled and a new IP Address has been entered and saved, power must be cycled on the unit before the new IP Address will be used.

When DHCP is enabled, the IP address, network mask and Gateway IP address will be requested from a local DHCP server. The user is responsible for providing a server to respond to these requests. If no DHCP server is available the MicroPak 2e will wait indefinitely for a



response. In addition, when DHCP is enabled, an Ethernet/IP controller can configure the MicroPak 2e to save the current configuration and use it at the next power cycle instead of requesting an address via DHCP. Similarly, the remote Ethernet/IP controller can also reconfigure the MicroPak 2e to request its IP configuration from a DHCP server at the next power cycle.

**NOTE**

➤ Beginning with V1.1.07, the user cannot change the “Ethernet IP” setting using this screen. Instead set the “Remote Option” setting described previously to be equal to ‘2’.

**Feedback Fault Menu**

This menu gives the user control over the use of the Feedback Fault. It allows this fault to be disabled and provides the means to modify the delay before a fault is generated after detection.

It also allows the user to modify the Communications Timeout value. The Communications Time Out value has a range of 500—5000 milliseconds with a default value of 1000. This parameter is used by the Display & Communications Control processor to determine how long to wait before signaling a fault when Ethernet/IP messages are not being received.

**HIGH VOLTAGE**

```

Feedback Fault→Ena←
FB Fault Delay 500
ComTimeOut 1000 msec
Quit Save_Changes ■
    
```

Figure 31: Feedback Menu Screen

**NOTE**

➤ The Feedback Fault settings should only be changed when adjacent indirect charge applicators cause Feedback Faults. In all other cases the defaults shown above should be used.

**Date Menu**

This menu allows the user to set the date and time for the controller’s real-time clock (RTC). The RTC information is then used by the controller to apply a timestamp to log file entries. This is done to aid in later analysis. As figure 32 shows, there are six settable values on the date and time screen. Month, Day, Year, Hours, Minutes and Seconds.

**HIGH VOLTAGE**

```

Date→11←26-2012
Time 10:08:30

Quit Save_Changes ■
    
```

Figure 32: Date Screen

**Change Passwords Menu**

This menu requires the user to enter the current password before they are allowed to set a new password. When the new password is entered, it will immediately be used for all values being changed.

**NOTE**

➤ The MicroPak 2e controller is shipped with the following default passwords:

**User - 7734 System - 7735**

It is recommended these be changed at installation by the customer, to prevent changes being made by anyone who has access to this manual.

**HIGH VOLTAGE**

```

Change Passwords:
User Password→????←
Sys Password ????
Cfg Password ???? ■
    
```

Figure 33: Change Passwords Screen

## Broadcast Control Menu

This menu allows the user to control the filtering of excessive broadcast packets. The principal use of this feature is as an aid in confirming the presence of excessive broadcast traffic. Setting Suppression to “Ena” will enable the removal of broadcast packets if the count of packets per measurement interval exceeds the percentage specified by Storm Level. In normal use this feature should be disabled. In addition, the MAC address assigned to the Display and Communications Processor board (DCP) is displayed at the top of the screen.




Figure 34: Broadcast Control Screen

## CONFIGURATION PARAMETERS AND SETTINGS

### Cascade Type

The MicroPak 2e Controller currently supports the following types of cascades.

- HP404
- HP505
- RP1000
- CONSOLIDATED
- RP404
- LEPS5002
- ATEX-HP404
- FM-HP404
- NONE (No Cascade attached. Permits MP2e to be used as a Speed Controller.)

#### NOTE

- The cascade type is configured by the factory based on the equipment ordered by the customer. In addition to configuring the controller for one of the cascade types shown above, the factory will also configure JMP2, JMP3 and JMP4 to match the cascade type.

### Date

This parameter consists of the Month, Day and Year which is maintained by the embedded real-time clock hardware. The controller uses it to apply a time stamp to log file entries.

### Time

This parameter consists of the Hour, Minute and Second which is maintained by the embedded real-time clock hardware. The controller uses it to apply a time stamp to log file entries.

### IP Address

This is the IP (Internet Protocol) address assigned to the controller. It is set by default to 192.168.0.3 but can be changed to allow the use of multiple MicroPak 2e Controllers and to accommodate the local network settings.

### Ethernet/IP

This parameter controls whether the MicroPak 2e Controller will allow a host system to connect and remotely configure and command the controller via an Ethernet/IP connection.

### Atomizer MIO

This parameter enables or disables the use of an MIO Atomizer Controller. This setting is factory configured.

### Discrete MIO

This parameter enables or disables the use of an MIO Discrete IO interface. This setting is factory configured.

### MiscIO

This parameter controls whether the MicroPak 2e Controller will use the state of the MiscIO hardware input in its control calculations.

### MiscIO Interlock or Trigger

This parameter controls whether the MiscIO hardware input will be used as an interlock signal or as a trigger to enable HV.

#### NOTE

- MiscIO must be enabled and Ethernet/IP disabled before the controller will allow the Trigger function to be selected.

**Booth (Air)**

This parameter controls whether the MicroPak 2e Controller will use the state of the Booth (Air) hardware input in its control calculations.

**Booth Interlock or Reset**

This parameter controls whether the Booth (Air) hardware input will be used as an interlock signal or as an HV Reset signal.

**NOTE**

➤ Booth must be enabled and Ethernet/IP disabled before the controller will allow the Reset function to be selected.

**Door**

This parameter controls whether the MicroPak 2e Controller will use the state of the Door hardware input in its control calculations.

**Unilink Mode**

This parameter indicates the status of Unilink operation. When enabled the MP2e uses the Unilink Select input to determine if a Bell or Gun is mounted. This is a factory configured setting.

**Unilink Select**

When Unilink Mode is enabled, this parameter allows the user to manually select either Bell or Gun to match the atomizer which is currently attached. This selection can also be made through the Ethernet/IP interface.

**Password**

This parameter is the value entered for the user password.

**System Password**

This parameter is the value entered for the system password.

**Mode**

The operating mode can be set to either Voltage or Current mode. The mode selection determines which independent setpoint (i.e. kVSet or  $\mu$ ASet) is the basis for control.

**Charge Type**

The charge type can be set to either DIRECT or INDIRECT type. This setting must match the type of charging provided by the applicator being used as it controls the calculations of the KV actual value.

Note the INDIRECT type can only be selected when an RP1000 no cascade is configured. All other cascades will force Charge Type to be configured as DIRECT.

The following table shows the passwords required to change the Configuration parameters.

TABLE 6	
Parameter	Password Level
Booth (Air)	System
Booth Interlock or Reset	System
Broadcast Suppress	System
Cabinet Type	Config
Cascade Type	Config
Charge Type	Config
ComTimeOut	System
Config Password	Config
Date	User
DHCP	System
Door	System
Ethernet/IP Enable	User
FB Fault Delay	System
Feedback Fault	System
IP Address	System
MiscIO	System
MiscIO Interlock or Trigger	System
Mode	Config
Storm Level	System
System Password	System
Time	User
uPak VI Limiting	Config
User Password	User
Remote Config	System
Array Member	System

**DIAGNOSTICS MENU**

Selecting Diagnostics from the Startup Menu shown in Figure 16 causes menu screens shown in Figures 35 and 36 to be displayed. Note that once the Diagnostic menu is entered, a power OFF cycle must be done to exit the Diagnostic menu.






Figure 35: Diagnostic Key Screen




Figure 36: Diagnostic Voltage Screen

Front Panel Switches

The first screen, Figure 35, only uses the first line of the display. This line begins with “Keys=” and is followed by single characters showing the current state of the front panel push buttons and switches. This allows a user to verify that all the front panel switches, shown above, work as expected.

Typically a lower case letter indicates the corresponding key is inactive while an upper case letter indicates activity. Working from left to right across the list of letters we have:

- “u U” - the Up arrow button.
- “d D” - the Down arrow button.
- “l L” - the Left arrow button.
- “r R” - the Right arrow button.
- “c C” - the SET button located in the Center of the arrows.
- “s S” - the Screen button.
- “a H” - the HV/AT button.
- “L R” - the Local/Remote switch.
- “o O” - the HV On switch.
- “r R” - the momentary HV off switch which is used to Reset faults.
- “a A” - the Atomizer on/off switch.
- “E e” - the External stop input. Note the “E” indicates the external contact is closed which is the state required for normal operation.

The second screen, Figure 36 shows A2D (Analog to Digital) readings for three of the system voltages along with the current system status. The items displayed are as follows:

**PWR** — this reading shows the main cascade power (+24V DC) connected to J4. It’s nominal value is 2820.

**LGIC** — this reading shows the Logic power (+24V DC) connected to J11. It’s nominal value is 2685.

**1.8V** — this reading shows the internal 1.8V DC power supply. It’s nominal value is 2320.

**Sts** — this shows the current system state which can be either Stopped or Faulted.

## OPERATING PARAMETERS AND SETTINGS

Once the system has been placed into Run mode operation, the Configuration settings previous described can no longer be adjusted.

There are also several additional operating High Voltage control parameter settings which can be adjusted with the system in RUN mode. This section describes these parameters.

### kVSet

This is the voltage setpoint, used in Voltage Control Mode. The system attempts to keep the voltage at this value when operating at low current levels, but as the current level is increased the voltage will be reduced to stay within the I-V curve of the selected cascade. When operating in Current Mode, kVSet is not displayed since the upper and lower voltage limits are determined by kV Low Limit and kV High Limit.




Figure 37: kv setpoint

**μASet**

This is the current setpoint, used in Current Control Mode. The system attempts to keep the current at this value when running.




Figure 38: uAmp setpoint

**di/dt Ena/Dis**

This allows the user to enable or disable the controller’s detection of rapid current increases. This feature is only available in Voltage Control Mode and is not recommended for indirect charge applications.

The Di/Dt detection feature improves the ability of the power supply to prevent discharges when a grounded object is approaching at rates greater than approximately 4 inches per second. Slower rates of approach are typically sensed by Max μA Limit, assuming Max μA Limit was properly set. The Di/Dt Sensitivity and Max μA Limit must be set correctly to minimize discharges when using metal (unlisted) applicators.




Figure 39: didt enabled disabled

**di/dt Sensitivity**

In Voltage Control Mode, this allows the user to control how rapid a current change can occur before a fault is generated. Allowable settings are 0 to 60, specified in units of μAmps per 100 milliseconds. For direct charge solvent borne applicators, a setting of 15 is suggested as a starting point.

Anytime a Di/Dt fault occurs, the cause of the fault must be determined before changes are made to the Di/Dt Sensitivity. If it is determined to be a nuisance fault, then the Di/Dt Sensitivity can be incremented to permit a larger current change per unit of time. This type of fault-analyze-adjust cycle must be performed repeatedly to be sure the minimum Di/Dt Sensitivity is being used.

**WARNING**

➤ Setting di/dt Sensitivity arbitrarily high will reduce the effectiveness of the setting in detecting unsafe operating conditions. To achieve the safest possible operation, the user should perform tests to determine the minimum setting which avoids nuisance faults.




Figure 40: didt sensitivity

**dv/dt Ena/Dis**

This allows the user to enable or disable the controller’s detection of rapid voltage changes. This is only available in Current Mode.




Figure 41: dv dt enabled disabled

**dv/dt Sensitivity**

In current control mode, this allows the user to control how rapid a voltage change can occur before a fault is generated. Allowable settings are 0 to 60 (kV per 100 milliseconds). A setting of 15 is suggested as a starting point for Solvent borne paint.

**WARNING**

➤ Setting dv/dt Sensitivity arbitrarily high will reduce the effectiveness of the setting in detecting unsafe operating conditions. To achieve the safest possible operation, the user should perform tests to determine the minimum setting which avoids nuisance faults.




Figure 42: dv dt sensitivity

**Max  $\mu$ A Limit**

This parameter determines the level where a Current Limit Fault occurs. It is the primary means of preventing discharges when the current level rises slowly. Therefore to ensure safe operation this setting, like the previously discussed Di/Dt Sensitivity, should be carefully set to the minimum value which eliminates nuisance faults. For Solvent borne applications, a value of 30 is a reasonable starting point.

When the current is greater than 90% of this value, a Current Limit Warning is generated. When the current rises above this value, it issues a Current Limit Fault.




Figure 43: max uAmp Limit

**kV Low Limit**

This parameter determines the level where a kV Low Limit Fault occurs. When the Voltage falls below this value, it issues a kV Lo Fault. It only applies in Current Mode.




Figure 44: kv low limit

**kV High Limit**

This parameter determines the level where a kV High Limit Warning occurs. When the voltage exceeds 90% of this value, it issues a kV High Limit Warning and prevents the voltage from exceeding the limit value. It only applies in Current Mode.




Figure 45: kv high limit

The following table lists the operating parameters and the passwords required to change each parameter.

TABLE 7	
Parameter	Password Level
kVSet	-none-
$\mu$ ASet	-none-
Di/Dt Enable	User
Di/Dt Sensitivity	User
Dv/Dt Enable	User
Dv/Dt Sensitivity	User
Max $\mu$ A Limit	System
KV Low Limit	-none-
KV High Limit	System

## CONTROL CONDITIONS

### Power Up

On power up, the system does several checks to determine hardware status. It checks various signals to determine that there are no faults, including feedback from the Variable Voltage Output and High Voltage Inputs to determine system status. If it determines that it is OK to start, the Check display on the run menu changes from VOL or INT to OK and System Status changes to OK.

### HV On

When the HV On signal is received and Check is OK, the system status changes to “Starting” and the Variable Voltage Output is increased until the Independent Value rises to within a tolerance window (currently +/-3) of the setpoint value. Then the System Status changes to “Running”.

### Setpoint Changed

If the setpoint changes outside the control window, the status changes to “Rising” or “Falling” until the Independent Value again reaches the control window at which point it returns to “Running”.

### HV Off

When HV Off is activated the system immediately sets the Variable Voltage Output to zero volts, disables the HV Relay and goes to Stop Mode.

The System Check goes to OK. However, before allowing the output to be enabled again, it checks the High Voltage and Variable Voltage Output feedback signals to verify that they have both decreased since the high voltage was disabled.

## SYSTEM STATUS (STS)

### STRT / RISE / FALL / STPG

System is changing from one voltage/current value to another. Di/dt and dv/dt checks are disabled. The abbreviations stand for Starting, Rising, Falling and Stopping.

### RUN

System is attempting to keep a steady value on Setpoint (the Independent Value). All enabled checks are active.

### STPD

System output is off and awaiting a command. The abbreviation stands for Stopped.

### WARN

System has detected a current or voltage condition within 10% of the limit settings. The abbreviation stands for Warning.

### FALT

System has detected a fault condition, stopped and will not allow starting until the fault is reset. If the fault condition has not been cleared, it may immediately fault without starting. The abbreviation stands for Fault.

## SYSTEM CHECK (CHK)

### OK

System has passed the checks and is ready to start.

### POWER

System is detecting a lack of cascade power.

### INTLK

System is detecting an interlock failure.

## SYSTEM FAULT BEHAVIOR

The following tables specify how High Voltage or Atomizer Faults effect the operation of each other.

### VOLTG

System has detected excessive voltage on the High Voltage or Variable Voltage Output Feedback signals and will not allow a start.

### NOTE

- Sometimes the operating conditions can cause VOLTG to display, such as:
  1. A system with multiple applicators near each other, where some applicators are ON/active and others are OFF/inactive. The inactive applicators can receive / detect the voltage generated and fed back by the active applicators.
  2. A system with an RP-404, which has a slow discharge rate (bleed-down), when the system is turned off. This VOLTG will display while the charge is dissipating, then changes to OK.

### INTLK

System is detecting an interlock failure.

## SYSTEM FAULT BEHAVIOR

The following tables specify how High Voltage or Atomizer Faults effect the operation of each other.

High Voltage Faults	HV Action	Atom Action
Interlock	Fault	Disable
Comm Time Out	Fault	Disable
Communications	Fault	Disable
Hardware	Fault	Disable
KV Low	Fault	No effect**
DIDT or DVDT	Fault	No effect**
HV Feedback	Fault	No effect**
Min Output	Fault	No effect**
Max KV	Fault	No effect**
Over Voltage	Fault	No effect**
Over Current	Fault	No effect**
Voltage Cable Fault	Fault	No effect**
Current Cable Fault	Fault	No effect**

The 1st table shows the four High Voltage Controller faults that will stop the Atomizer along with 9 which will leave the Atomizer in its current state. These faults are all reported over Ethernet/IP.

\*\* The atomizer will continue to operate when these faults occur, but the Paint Triggers will be inhibited as a safety precaution to prevent the possibility of feeding a fire.

The second table shows that ALL Atomizer Faults will stop the High Voltage Controller.

Other HV Faults	HV Action	Atom Action
Bell Overspeed	Disable	Fault
Bell Underspeed	Disable	Fault
Loss Of Feedback	Disable	Fault
Low Bearing Air	Disable	Fault
Comm. Lost	Disable	Fault

The third table shows five other miscellaneous faults. Note the HVC WDog Reset fault causes the Atomizer to stop since it will loose it's communications link.

Other HV Faults	HV Action	Atom Action
Remote Stop	Fault	Disable
HVC Power OFF	Fault	Disable
System Mode	Fault	No effect
HVC WDog Reset	Fault	*RansNet Lost Fault
DCP WDog Reset	Fault	No effect

## Ethernet/IP INTERFACE

The Ethernet/IP Interface for the MicroPak 2e Controller is defined as a set of four 16 bit words of input plus a set of four 16 bit words of output. The Assembly instances are defined for the controller as follows:

Instance	Number	Count	Size
Input	100. (0x64)	4	16 bits
Output	116. (0x74)	4	16 bits
Configuration	1. (0x01)	0	8 bits

### NOTE

- When defining the IO Instances to the host system, specify the input object of the controller as the output object of the host and the output object of the controller as the input object of the host.
- The Ethernet/IP interface of the MicroPak 2e only supports Real-Time Implicit messaging using the Assemblies specified in this manual. The use of Explicit messaging to read and set individual parameters is not supported.
- Sending commands to the MP2e while it is starting up and has not yet entered RUN STATE should be avoided as it may result in unexpected behavior. Starting with V1.1.02, any incoming Ethernet/IP commands will be ignored until the MP2e has entered RUN STATE.

The Input bit definitions are shown in Table 8 and the Output bit definitions are shown in Table 9 on the following pages.

## Description of Interface Elements

### Input Word 0

**Bit 0 - Enable Control**

When this bit is set (high) the system will attempt to keep the actual at the appropriate setpoint.

**Bit 1 - Reset Faults**

When this bit is changed from low to high (cleared to set) the system will clear any fault bits if any are set and will set the communication fault if no fault bits are set.

**Bit 2 - Current Mode**

When this bit is set, the system will operate in the Current Control Mode and when cleared will operate in the Voltage Control Mode.

**Bits (3-15) - Unused**

These bits are currently undefined and unused.

### Input Word 1

**Bits (0-7) - kV Setpoint**

This byte (8 bit) value determines the active Voltage setpoint in kV.

**Bits (8-15) -  $\mu$ A Setpoint**

This byte (8 bit) value determines the active Current setpoint in  $\mu$ A.

### NOTE

➤ When an RP1000 or LEPS5002 cascade is selected, this value is multiplied by 5 to set the actual  $\mu$ A setpoint.

### Input Word 2

**Bits (0-7) - Parameter Value**

These bits are currently undefined and unused.

**Bit (8-14) - Parameter Select Code**

This 7 bit value determines the parameter to change.

**Bit 15 - Parameter Write Strobe**

When this bit changes from cleared to set, the parameter value is written into the selected parameter and displayed in the Output Word 2.

### Input Word 3

**Bits (0-7) - Unused**

These bits are currently undefined and unused.

**Bits (8-14) - Parameter Select Code**

The 7 bit value determines the parameter to change.

**Bit 15 - Parameter Read Strobe**

When this bit changes from cleared, to set the Current Parameter Value is read from the selected parameter and displayed in the Output Word 3.



**TABLE 8 - MICROPAK 2e Ethernet/IP INPUT DEFINITIONS  
INPUT OBJECT (0X64)**

Bit	Word 0	Word 1	Word 2	Word 3
0	HV Enable Control	kV Setpoint	Parameter Value	
1	Reset Faults	kV Setpoint	Parameter Value	
2	Current Mode	kV Setpoint	Parameter Value	
3		kV Setpoint	Parameter Value	
4		kV Setpoint	Parameter Value	
5		kV Setpoint	Parameter Value	
6		kV Setpoint	Parameter Value	
7		kV Setpoint	Parameter Value	
8		μA Setpoint	Parameter Select Code	Parameter Select Code
9		μA Setpoint	Parameter Select Code	Parameter Select Code
10		μA Setpoint	Parameter Select Code	Parameter Select Code
11		μA Setpoint	Parameter Select Code	Parameter Select Code
12		μA Setpoint	Parameter Select Code	Parameter Select Code
13		μA Setpoint	Parameter Select Code	Parameter Select Code
14		μA Setpoint	Parameter Select Code	Parameter Select Code
15		μA Setpoint	Parameter Write Strobe	Parameter Read Strobe

**TABLE 9 - MICROPAK 2e Ethernet/IP OUTPUT DEFINITIONS  
OUTPUT OBJECT (0X44)**

Bit	Word 0	Word 1	Word 2	Word 3
0	In Control	Over Current Warning	Parameter Data Value	Actual kV Value
1	Ramping	Over Voltage Warning	Parameter Data Value	Actual kV Value
2	OK to Start	Under Voltage Warning	Parameter Data Value	Actual kV Value
3	Remote Mode	Max Output Warning	Parameter Data Value	Actual kV Value
4	HV On Echo	Communications Time Out Fault	Parameter Data Value	Actual kV Value
5	Warning	Interlock Fault	Parameter Data Value	Actual kV Value
6	Fault	Communications Fault	Parameter Data Value	Actual kV Value
7	Current Mode	Hardware Fault	Parameter Data Value	Actual kV Value
8	Atomizer Fault	Low Voltage Fault	Parameter Select Code	Actual μA Value
9	Door Interlock Status	dv/dt Fault	Parameter Select Code	Actual μA Value
10	Booth Air Interlock Status	di/dt Fault	Parameter Select Code	Actual μA Value
11	Miscellaneous Interlock Status	Minimum Output Fault	Parameter Select Code	Actual μA Value
12	Remote Stop (Interlock) Status	Feedback Fault	Parameter Select Code	Actual μA Value
13	Not in RUN STATE	Over Voltage Fault	Parameter Select Code	Actual μA Value
14		Over Current Fault	Parameter Select Code	Actual μA Value
15	Heartbeat	Cable Fault	Parameter Acknowledge	Actual μA Value

## Output Word 0

### **Bit 0 - In Control**

This bit is set when control is enabled and the controlled value has reached within three of the setpoint. This does not mean that the value is still within three of the setpoint, but that it had been at one time.

### **Bit 1 - Ramping**

This bit is set when the setpoint has been changed and the controlled value has not yet come within three of the setpoint value.

During the time this bit is set, the di/dt and dv/dt checks are not active.

### **Bit 2 - OK to Start**

This bit is set when the system determines that the voltage values are in a range where it is allowed to start control. Will remain 0 until the MP2e enters the RUN STATE.

### **Bit 3 - Remote Mode**

This bit is set when the front panel switch is set to remote. When set, an external unit can control the system.

### **Bit 4 - HV On Echo**

This bit is set whenever HV is ON

### **Bit 5 - Warning**

This bit is set whenever any warning is in effect.

### **Bit 6 - Fault**

This bit is set whenever any fault is in effect (see "Fault Descriptions" in "Troubleshooting Guide" in the "Maintenance" section).

### **Bit 7 - Current Mode**

This bit is set when Current Mode Control is active.

### **Bit 8 - Atomizer Caused Fault**

This bit indicates that an Atomizer Fault caused the shutdown.

### **Bit 9 - Door Interlock Status**

This bit is set when the interlock was open when the HVC Fault occurred.

### **Bit 10 - Booth Air Interlock Status**

This bit is set when the interlock was open when the HVC Fault occurred.

### **Bit 11 - Miscellaneous Interlock Status**

This bit is set when the interlock was open when the HVC Fault occurred.

### **Bit 12 - Remote Stop (Interlock) Status**

This bit is set when the interlock was open when the HVC Fault occurred.

### **Bit 13 - Not in RUN STATE**

This bit is set when the MP2e is not in RUN STATE. This provides an indication when the MP2e has changed from a BOOTING STATE to the RUN STATE. This was added in V1.1.02 to allow remote detection of an MP2e being inadvertently left in Local mode after power is cycled.

### **Bit 14 - Unused**

Currently undefined.

### **Bit 15 - Heartbeat**

This bit changes state every 1/4 second producing two pulses per second.

## Output Word 1

### **Bit 0 - Over Current Warning**

The current value is within 10% of the upper limit.

### **Bit 1 - Over Voltage Warning**

The voltage value is within 10% of the upper limit in current mode.

### **Bit 2 - Under Voltage Warning**

The voltage value is within 10% of the lower limit in current mode.

### **Bit 3 - Max Output Warning**

The control voltage has reached its maximum value.

### **Bit 4 - Communication Time Out Fault**

The system has detected a communication loss which was greater than the value specified by ComTimeOut.

### **Bit 5 - Interlock Fault**

The system has detected one of the active interlock input in an open state.

### **Bit 6 - Communication Fault**

The system has detected a communication failure after an Ethernet/IP connection was initiated.

### **Bit 7 - Hardware Fault**

The system has detected a fatal System Failure.



**Bit 8 - Low Voltage Fault**

The system has fallen below the kV Limit Lo while in Current Mode.

**Bit 9 - Not Used****Bit 10 - di/dt Fault or dv/dt Fault**

The system has detected a di/dt fault (Voyage Mode) or dv/dt fault (Current Mode).

**Bit 11 - Minimum Output Fault**

The system has lowered the Variable Voltage Output to zero and still is above the setpoint.

**Bit 12 - Feedback Fault**

The system has measured an high level of voltage or current feedback .which does not correspond to the level of the control outputs being applied.

**Bit 13 - Over Voltage Fault**

The system has exceeded the kV Limit Hi or the Max System Limit.

**Bit 14 - Over Current Fault**

The current value has exceeded the Current (I) Limit Hi or the Max SystemLimit.

**Bit 15 - Cable Fault**

This bit is set whenever the voltage or current feedback from the cascade has been lost or fallen below the acceptable value.

**Output Word 2****Bits (0-7) - Parameter Data Value**

This byte (8 bit) tells the system the active parameter value.

**Bits (8-14) - Parameter Select Code**

This 7 bit value tells the system which parameter is being displayed.

**Bit 15 - Parameter Acknowledge**

When this bit changes from cleared to set a new Parameter Value is being displayed. It is cleared when the Parameter Read Strobe and Parameter Write Strobe are both cleared.

**Output Word 3****Bits (0-7) - Actual kV Value**

The byte (8 bit) value displays the latest voltage reading in kV.

**Bits (8-15) - Actual  $\mu$ A Value**

This byte (8 bit) value displays the latest current reading in  $\mu$ A.

**NOTE**

- When an RP1000 or LEPS5002 cascade is selected, the  $\mu$ A value returned is the actual value divided by 5.

**Parameter Select Codes****Parameter Select = 1: DvDt**

READ - returns value of DvDT threshold  
WRITE - sets value of DvDT threshold

**Parameter Select = 2: DiDt**

READ - returns value of DiDT threshold  
WRITE - sets value of DiDT threshold

**Parameter Select = 3: kVHi**

READ - returns value of max KV allowed  
WRITE - sets value of max KV allowed

**Parameter Select = 4: iHi**

READ - returns value of max I allowed  
WRITE - sets value of max I allowed

**NOTE**

- When an RP1000 or LEPS5002 cascade is selected, the  $\mu$ A value passed is scaled by 5 from the actual value.

**Parameter Select = 5: kVLo**

READ - returns value of kVLo  
WRITE - sets value of kVLo

**Parameter Select = 6: DxDtEna**

READ - returns value of DxDtEna  
WRITE - sets value of DxDtEna

**NOTE**

- DxDtEna will enable the DxDt check available in the control mode currently active. I.E. DiDT when in Voltage Mode and DvDT when in Current Mode.

- Parameter Select = 7: Password 1**  
READ - returns first character of user password  
WRITE - (Unsupported)
- Parameter Select = 8: Password 2**  
READ - returns second character of the password
- Parameter Select = 9: Password 3**  
READ - returns third character of user password  
WRITE - (Unsupported)
- Parameter Select = 10: Password 4**  
READ - returns fourth character of user password  
WRITE - (Unsupported)

**TABLE 10**

Parameter	Min Value	Max Value
DvDT	0	60
DiDt	0	60
kVHi	20	100
iHi	10	Per Cascade
kVLo	0	80
DxDtEna	0 = Disable	1 = Enable
Password 1	0	9
Password 2	0	9
Password 3	0	9
Password 4	0	9

**NOTE**

- The per Cascade iHi values can be found in the Electrical Specifications located in the Introduction section.

# Ransburg Atomizer Controller



# Atomizer Controller - INTRODUCTION

## ATOMIZER CONTROLLER GENERAL DESCRIPTION

The Atomizer Controller for use with the MicroPak 2e Controller is designed to continuously monitor and maintain the programmable speed of a rotary atomizer as well as provide a universal I/O interface for many atomizer functions. This module utilizes closed-loop control via a fiber optic cable to maintain the rotator speed. A number of configuration options are available to the end user. These include built in support for many Ransburg rotary atomizers as well as an assortment of inputs and outputs available to the user.




Figure 46: MicroPak 2e Multi I/O Board

## SPECIFICATIONS (At Sea-Level Conditions)

### Environmental/Physical

<b>Operating Temperature:</b>	0°C to +55°C
<b>Storage &amp; Shipping Temp.:</b>	-40°C to +85°C
<b>Humidity:</b>	95% Non-Condensing
<b>Physical Size:</b>	2" tall X 7.5" X 4.75" (51mm x 191mm x 121mm)
<b>Mounting:</b>	Figure 48 in Appendix

### Environmental Requirements

<b>Power Required:</b>	
<b>J15 - Controller :</b>	24V DC @ 0.25 Amps No IO's
<b>Note:</b> 24V DC power supply must be regulated and have over current and over voltage protection.	

### Electrical - Communication Requirements

<b>Control and Reporting:</b>	Ethernet/IP (Implicit Messaging only)
-------------------------------	---------------------------------------

### Electrical - Controls in Local Mode

<b>Analog In:</b>	(0-10V or 4-20mA) <b>BEARING AIR FEEDBACK</b>
<b>Analog Out:</b>	(0-10V or 4-20mA with option) <b>BELL DRIVE</b> , Bell Speed Read Out
<b>Discrete In:</b>	(0-24V) (None Active)
<b>Discrete Out:</b>	(0-24V, Current Sourcing) <b>BRAKE</b> , Overspeed Warn/Fault, Underspeed Warn/Fault, Loss of Bell Feedback Warn/Fault, Low Bearing Air Warn/Fault, Speed Out of Tolerance Warn
<b>NOTE:</b> In Local Mode, the functions of the Analog and Discrete input signals are performed by the Front Panel user interface.	

(Continued on next page)

**SPECIFICATIONS** (At Sea-Level Conditions) (Cont.)**NOTE**

➤ Signals shown above in **BOLD** are minimum required functions for Atomizer control to operate. This note regarding the I/O names in **BOLD** also applies to the following descriptions.

**Electrical - Controls in Remote Ethernet/IP Mode**

<b>Analog In:</b>	(0-10V or 4-20mA) <b>BEARING AIR FEEDBACK</b>
<b>Analog Out:</b>	(0-10V or 4-20mA with option) <b>BELL DRIVE</b> , Bell Speed Read Out, Flowrate #1, Flowrate #2, Shaping Air #1, Shaping Air #2
<b>Discrete In:</b>	(0-24V) User Input #1, User Input #2
<b>Discrete Out:</b>	(0-24V, Current Sourcing) <b>BRAKE</b> , Paint Trigger #1, Paint Trigger #2, Dump #1, Dump #2, Fluid Override #1, Fluid Override #2, Cup Wash, Atomizer Faulted, HV On, User Output #1, User Output #2

**Electrical - Controls in Remote Discrete Mode**

<b>Analog In:</b>	(0-10V or 4-20mA) <b>BEARING AIR FEEDBACK</b> , Bell Speed Setpoint, Flowrate Setpoint #1, Flowrate Setpoint #2, Shaping Air Setpoint #1, Shaping Air Setpoint #2
<b>Analog Out:</b>	(0-10V or 4-20mA with option) <b>BELL DRIVE</b> , Bell Speed Read Out, Flowrate #1, Flowrate #2, Shaping Air #1, Shaping Air #2
<b>Discrete In:</b>	(0-24V) <b>BELL SPIN ENABLE</b> , Paint Trigger #1, Paint Trigger #2, Dump #1, Dump #2, Fluid Override #1, Fluid Override #2, Cup Wash
<b>Discrete Out:</b>	(0-24V, Current Sourcing) <b>BRAKE</b> , Paint Trigger #1, Paint Trigger #2, Dump #1, Dump #2, Fluid Override #1, Fluid Override #2, Cup Wash, Overspeed Warn/Fault, Low Bearing Air Warn/Fault, Loss of Bell Feedback Warn/Fault, Speed Out of Tolerance Warn, Atomizer Failed, HV On

## SPEED CONTROL

The Atomizer Controller is used in a closed-loop rotational speed control system for rotary atomizers as shown in Figure 47. It accepts a requested speed command and, after comparing this with the actual speed feedback from the atomizer, provides an output to maintain the requested speed.

When a speed request is received, the controller activates the Turbine Drive signal which controls the output of an E to P transducer providing an air pilot signal to a 1:1 volume booster. The volume booster supplies high volume drive air to the rotary atomizer.

The atomizer speed is monitored by a fiber optic cable to a fiber optic transceiver mounted on the Atomizer Controller board. The transceiver provides a speed feedback signal to the Atomizer Controller which is timed to determine the rotational speed. The speed, in increments of 1000's rpm, is displayed on the MicroPak 2e Controller front panel.

An optional braking system provides for rapid slowdown. When changing speeds from high to low (change greater than 3,000 rpm), the controller provides an electrical brake signal to drive a pneumatic solenoid which delivers high pressure air to the brake input of the atomizer. Ransburg part numbers, for each of the components described, are listed in the MicroPak 2e High Voltage Controller Parts List located in this manual.

**NOTE**

- A speed command of 1 krpm is recognized by the controller as an emergency stop condition and will cause the brake to stay engaged until the speed reaches 2 krpm from which the turbine will coast to a stop.
- A speed command of 0 krpm does not actuate the brake but allows the turbine to coast to a stop condition.




Figure 47: MicroPak 2e Controller/Atomizer Minimal System



The speed feedback signal is designed to drop out at about 2 krpm and the controller will set a Loss of Feedback Fault. A new speed command will reset the fault at the Atomizer Controller, but the MicroPak 2e Controller will only reset its fault indication when commanded by the Ethernet/IP interface or the front panel HV On/Off switch.

An electrical input is provided and required for atomizer bearing air sensing and interlock. Minimum bearing air pressure threshold is set at 80 psi.

The following table lists the maximum allowed speed and minimum bearing air for atomizers supported by the Atomizer Controller. While there are no minimum speed limits set by the Atomizer Controller, the low speed operation is limited by the drop out of the speed feedback signal at about 2 krpm.

Atomizer Type	Max K RPM	Min Bearing Air PSI
RMA300-500	100	80
RMA303-SBA	70	70
AeroBell	60	80
AeroBell33	55	80
RMA100-200	50	80
TurboDisk	40	-
AutoGun	-	-
RMA-550	55	80

# Atomizer Controller - OPERATION

## OPERATION

The Atomizer Controller currently supports three different operating modes with varying levels of capabilities.

### Remote Ethernet/IP Control

This mode gives the remote system full access to the atomizer parameters and allows control of starting and stopping as well as collection of fault information.

### Remote Discrete Control

This mode is only available when Ethernet/IP is disabled. While it provides no access to the atomizer parameters, it does allow the remote system to control starting, stopping and various other functions provided through the Atomizer Controller inputs and outputs. See tables 16, 17, 18, and 19 for a complete list of I/O functions.

### Local Front Panel Control

This mode is available whenever the MicroPak 2e Controller is in Local mode. In the current software release, operation is limited to starting and stopping the atomizer by means of the Atomizer On/Off switch located on the front panel.

#### NOTE

► In local mode the Turbine Speed Set point can be set from the front panel and that value will be used for local operation. Upon exiting Local mode, control of the Turbine Speed Setpoint reverts to either the Ethernet/IP interface or the Discrete inputs.

## CONFIGURATION MENUS

The following four menus are displayed on the ATOMIZER screen (right panel). They are included in the base MicroPak 2e Controller but are only displayed when an Atomizer and/or Discrete IO Controller board is configured.

### Atomizer/Discrete IO Config Menu

This menu shows if the Atomizer or Discrete IO controllers were configured by the factory.




Figure 48: Atomizer Use Screen

### Atomizer Configuration Menu

The Atomizer Configuration menu displays the factory configured Atomizer type on the first line and the minimum bearing air pressure it requires on the second line. The third line displays whether or not Unilink operation was ordered with the controller. When Unilink operation is enabled, the fourth line allows the user to manually select which atomizer is attached, i.e. Bell or Gun. The selection is ignored if Unilink Mode is disabled.




Figure 49: Bearing Air SetPoint Screen

### Atomizer / Discrete IO Analog Inputs Menus

These screens allow the user to select the mode of each analog input on the Atomizer and Discrete IO Controllers. Two options are available, "V" or "I". "V" represents a 0-10 volt input and "I" represents a 4-20 milliamp input.




Figure 50: Atomizer Analog Input Screen




Figure 51: Discrete IO Analog Input Screen

**NOTE**

➤ Jumpers JMP15 through JMP9 must be set to match the selections on the Analog Inputs screens. For further information see the operation section of the Atomizer Controller or Discrete IO Controller portion of this manual.

## CONFIGURATION PARAMETERS AND SETTINGS

### Atomizer

This Atomizer controller currently supports the following types of atomizers.

- RMA300-500
- RMA303-SBA
- AeroBell
- AeroBell 33
- RMA100-200
- TurboDisk
- Auto Gun
- RMA-550

**NOTE**

➤ The RMA-550 Atomizer cannot be selected unless the Cascade is set to FM-HP404 and the Control Mode is set to Voltage. Once the RMA-550 Atomizer is selected, the Cascade type and Control Mode cannot be changed until the Atomizer selection is changed.

➤ The Auto Gun Atomizer cannot be selected if the Unilink Mode is enabled. Once the Auto Gun Atomizer is selected, the Unilink Mode cannot be enabled until the Atomizer selection is changed.

**WARNING**

➤ ONLY USE the type of atomizer which the controller was configured for by the factory. Using a different type atomizer may allow for operation outside the recommended parameters and values for the applicator and can result in damage or unsafe operation.

**TABLE 11**

Parameter	Password Level
ATOMIZER MIO Settings	
Atom Analog Inputs	System
Atomizer MIO	Config
Atomizer Type	Config
Unilink Mode	Config
Unilink Select	System

## OPERATING PARAMETERS AND SETTINGS

### Turbine Speed Setpoint

This parameter sets the turbine speed which will be commanded by the controller when in LOCAL mode. When in Remote mode it displays the speed setpoint commanded by the remote controller.

**NOTE**

➤ The following Atomizer settings and features are only available when the Atomizer Controller is configured for use with a ControlPak.

### Atomizer Shape Air Menu

This menu allows the user to manually adjust both the shaping air outputs and the paint flow rate outputs. The values used are expressed as percentages since the controller can be configured to provide either 0-10 V or 4-20 mA analog outputs.




Figure 52: Shape Menu Screen

**ShapeAirSP1**

This parameter determines the level in percent (i.e. 0-100%) that will be applied to the Shaping Air 1 output.

**ShapeAirSP2**

This parameter determines the level in percent (i.e. 0-100%) that will be applied to the Shaping Air 2 output.

**PFlowRateSP1**

This parameter determines the level in percent (i.e. 0-100%) that will be applied to the Paint Flow Rate 1 output.

**PFlowRateSP2**

This parameter determines the level in percent (i.e. 0-100%) that will be applied to the Paint Flow Rate 2 output.

**Atomizer Fluid Maintenance Menu**

This menu enables the user to safely perform paint flow calibration or flushing operations by disabling the Fluid Interlocks. Disabling the fluid interlocks cause both the high voltage and atomizer to be disabled (forced off). While at the same time allowing the paint and solvent triggers to occur without checking the rotational speed of the atomizer.

this interlock is to prevent fluid from being applied when it could easily flood the turbine. The second interlock prevents the solvent control output (i.e. Bell Cup, Disk or Gun Wash) from activating when the high voltage controller is active. This is done to minimize the risk of a fire caused by a high voltage discharge while solvent fluid is present.

TABLE 12	
Parameter	Password Level
Turbine Speed Setpoint	-none-
Shaping Air 1	User
Shaping Air 2	User
Paint Flow Rate 1	User
Paint Flow Rate 2	User
FluidInterLock	System

**AUTOMATIC SHUTDOWN**

The Atomizer Controller continuously monitors turbine operation and detects common fault conditions and will automatically stop the atomizer when one is detected.




Figure 53: Atomizer Maint Menu Screen

**FluidInterLock**

This parameter allows the user to disable the fluid interlocks between the high voltage controller and the atomizer controller. It is intended to allow maintenance activities such as paint flow calibrations. In addition, it can be used in an emergency to allow flushing of an atomizer when it cannot be run up to speed.

A description of the fluid interlocks follows:

There are two fluid interlocks implemented in the Atomizer which this parameter enables or disables. The first interlock normally prevents the Atomizers Paint Trigger and Wash outputs from being activated when the atomizer is below a minimum safe speed for fluid application. The purpose of

- Overspeed:** If the speed feedback exceeds the speed setpoint.  
 Liquid Bell - 10,000 rpm above setpoint  
 Disk - any speed over 30 krpm  
 Time delay is 0.5 seconds
- Underspeed:** If the speed feedback is less than the speed setpoint:  
 Liquid Bell - 10,000 rpm under setpoint  
 Disk - No underspeed checks made  
 Time delay is 0.5 seconds.
- Loss of Feedback:** Senses when feedback should be present but is not.  
 Pulses received from the fiber optics must be no greater than 800 msec apart during normal operation.  
 Start-up delay:  
 Liquid Bell - 1 second for the first pulse  
 Disk - 7 seconds  
 Once the first pulse has been received, the 800 msec interval applies.
- Invalid Speed Command:** Will not process speed requests higher than rated maximum. Internally set speed command to zero.

5. **Low Bearing Air Pressure:** If the bearing air pressure feedback drops below the minimum bearing air threshold. There is a 4 second time delay for all settings.
6. **Interlock Open:** If an active interlock is opened while the atomizer is running, all outputs will be disabled and a brake assisted ESTOP will be done before faulting.

### Out of Tolerance (WARNING)

Speed is not within +/- 5% of setpoint, no internal action taken, 1 second delay.  
Signal may be used externally as desired.

## INTERFACING CONSIDERATIONS

When using an Atomizer there are some operational restrictions that must be observed to avoid damaging the turbine. Six of these conditions were listed in the Automatic Shutdown section and are automatically enforced by the Atomizer Controller. There are also two other conditions which the controller is programmed to prevent. Both involve stopping the flow of paint to the bell. 1) When the Atomizer is not spinning, and 2) When the HV has faulted. These operational interlocks are accomplished by deactivating the signals *Paint Trigger #1* and *Paint Trigger #2* whenever the Atomizer is not running, or the HV controller is *FAULTED*.

### ⚠ CAUTION

- If the user chooses not to use the discrete outputs *Paint Trigger #1* and *Paint Trigger #2* provided by the Atomizer Controller, then they are responsible for implementing comparable interlocks between Atomizer and HV operation and paint flow. Failure to do so may result in a turbine failure or increased risk of a fire.

## USER DEFINED I-O'S

When the Ethernet/IP Interface for the Atomizer Controller is enabled, the definition of the discrete IO's is expanded to provide two user defined discrete inputs and two discrete outputs. The two inputs are passed directly to the PLC or Robot via the Ethernet/IP interface. Both inputs are available for use by the control system to read the state of suitable input signals. Similarly, the two outputs are under the direct control of the PLC or Robot via the Ethernet/IP interface.

The inputs are designed to accept a 0 to 24 VDC signal and the outputs provide a 0 to 24 VDC signal which can source up to 250 mA.

## Ethernet/IP INTERFACE

The Ethernet/IP Interface for the Atomizer Controller is defined as two assembly instances that contain the MicroPak 2e interface in the first four words of the input and output sets. Six additional words for the Atomizer Controller have been added at the end of the MicroPak 2e Ethernet/IP interface.

This means that the Atomizer Controller interface is a set of ten 16 bit words of input plus a set of ten 16 bit words of output. The Assembly instances are defined as objects 101 (0x65) and 117 (0x75), where object 101 is the input assembly and object 117 is the output assembly. A Configuration assembly is not used and can be defined as 1 with a size of 0.

Since the first four words of the Atomizer Controller interface are identical to those defined for the MicroPak 2, the following interface description only includes the six words which are specific to the Atomizer Controller. The Input bit definitions are shown in Table 11 and the Output bit definitions are shown in Table 12 on the following pages.

### NOTE

- When defining the IO Instances to the host system, specify the input object of the controller as the output object of the host and the output object of the controller as the input object of the host.
- The Ethernet/IP interface of the MicroPak 2e only supports Real-Time Implicit messaging using the Assemblies specified in this manual. The use of Explicit messaging to read and set individual parameters is not supported.
- Sending commands to the MP2e while it is starting up and has not yet entered RUN STATE should be avoided as it may result in unexpected behavior. Starting with V1.1.02, any incoming Ethernet/IP commands will be ignored until the MP2e has entered RUN STATE.

**TABLE 13 - ATOMIZER CONTROLLER Ethernet/IP INPUT BIT DEFINITIONS INPUT OBJECT (0X65)**

Bit	Word 4	Word 5	Word 6	Word 7	Word 8	Word 9
0	Atomizer Enable	RPM Setpoint	ShapeAir 1 Setpoint	ShapeAir 2 Setpoint	Param Read Code	Parameter Value
1	Reset Faults	RPM Setpoint	ShapeAir 1 Setpoint	ShapeAir 2 Setpoint	Param Read Code	Parameter Value
2		RPM Setpoint	ShapeAir 1 Setpoint	ShapeAir 2 Setpoint	Param Read Code	Parameter Value
3		RPM Setpoint	ShapeAir 1 Setpoint	ShapeAir 2 Setpoint	Param Read Code	Parameter Value
4	Paint Trigger #1	RPM Setpoint	ShapeAir 1 Setpoint	ShapeAir 2 Setpoint	Param Read Code	Parameter Value
5	Dump #1	RPM Setpoint	ShapeAir 1 Setpoint	ShapeAir 2 Setpoint	Param Read Code	Parameter Value
6	Fluid Override #1	RPM Setpoint	ShapeAir 1 Setpoint	ShapeAir 2 Setpoint	Param Read Code	Parameter Value
7		RPM Setpoint	ShapeAir 1 Setpoint	ShapeAir 2 Setpoint	Param Read Strobe	Parameter Value
8	Paint Trigger #2		FlowRate 1 Setpoint	FlowRate 2 Setpoint	Parameter Write Code	Parameter Value
9	Dump #2		FlowRate 1 Setpoint	FlowRate 2 Setpoint	Parameter Write Code	Parameter Value
10	Fluid Override #2		FlowRate 1 Setpoint	FlowRate 2 Setpoint	Parameter Write Code	Parameter Value
11			FlowRate 1 Setpoint	FlowRate 2 Setpoint	Parameter Write Code	Parameter Value
12	Bell Cup Wash		FlowRate 1 Setpoint	FlowRate 2 Setpoint	Parameter Write Code	Parameter Value
13			FlowRate 1 Setpoint	FlowRate 2 Setpoint	Parameter Write Code	Parameter Value
14	User Output #1		FlowRate 1 Setpoint	FlowRate 2 Setpoint	Parameter Write Code	Parameter Value
15	User Output #2		FlowRate 1 Setpoint	FlowRate 2 Setpoint	Parameter Write Strobe	Parameter Value



## Input Word 4

### **Bit 0 - Atomizer Enable**

When this bit is set (high) the system will attempt to keep the actual at the appropriate setpoint.

### **Bit 1 - Reset Atomizer Faults**

When this bit is changed from low to high (cleared to set) the system will clear any fault bits if any are set and will set the communication fault if no fault bits are set.

### **Bit 2 - Unused**

This bit is currently unused

### **Bit 3 - Unused**

This bit is currently unused

### **Bit 4 - Paint Trigger #1**

When this bit is set, the system will activate the Paint Trigger #1 output and when cleared will deactivate the Paint Trigger #1 output. This output is only active when the bell is running and no HV faults are present.

### **Bit 5 - Dump #1**

When this bit is set, the system will activate the Dump #1 output and when cleared will deactivate the Dump #1 output.

### **Bit 6 - Fluid Override #1**

When this bit is set, the system will activate the Fluid Override #1 output and when cleared will deactivate the Fluid Override #1 output.

### **Bit 7 - Unused**

This bit is currently unused.

### **Bit 8 - Paint Trigger #2**

When this bit is set, the system will activate the Paint Trigger #2 output and when cleared will deactivate the Paint Trigger #2 output. This output is only active when the bell is running and no HV faults are present.

### **Bit 9 - Dump #2**

When this bit is set, the system will activate the Dump #2 output and when cleared will deactivate the Dump #2 output.

### **Bit 10 - Fluid Override #2**

When this bit is set, the system will activate the Fluid Override #2 output and when cleared will deactivate the Fluid Override #2 output.

### **Bit 11 - Unused**

This bit is currently unused.

### **Bit 12 - Bell Cup Wash**

When this bit is set, the system will activate the Bell Cup Wash output and when cleared will deactivate the Bell Cup Wash output.

### **Bit 13 - Unused**

This bit is currently unused.

### **Bits (14-15) - User Outputs #1 and #2**

These bits give an integrator the ability to control two discrete outputs, which can be used by their external control system.

## Input Word 5

### **Bits (0-7) - RPM Setpoint**

This byte (8 bit) value determines the active atomizer speed setpoint in thousands of RPMs.

### **Bits (8-15) - Unused**

These bits are currently unused.

## Input Word 6

### **Bits (0-7) - Shape Air 1 Setpoint**

This byte (8 bit) value determines the Shaping Air 1 setpoint in % of full scale.

### **Bits (8-15) - Flow Rate 1 Setpoint**

This byte (8 bit) value determines the Flow Rate 1 setpoint in % of full scale.

## Input Word 7

### **Bits (0-7) - Shape Air 2 Setpoint**

This byte (8 bit) value determines the Shaping Air 2 setpoint in % of full scale.

### **Bits (8-15) - Flow Rate 2 Setpoint**

This byte (8 bit) value determines the Flow Rate 2 setpoint in % of full scale.

**Input Word 8**

**Bits (0-6) - Parameter Read Code**

This 6 bit value determines the parameter to read.

**Bit 7 - Parameter Read Strobe**

When this bit changes from cleared to set, the parameter value is read from the selected parameter and displayed in Output Word 7.

**Bits (8-14) - Parameter Write Code**

This 6 bit value determines the parameter to set.

**Bit 15 - Parameter Write Strobe**

When this bit changes from cleared to set, the parameter value is written into the selected parameter and displayed in Output Word 7.

**Input Word 9**

**Bits (0-15) - Parameter Value**

This 16 bit value is written to the parameter being changed.

**TABLE 14 - ATOMIZER CONTROLLER Ethernet/IP OUTPUT BIT DEFINITIONS OUTPUT OBJECT (0X75)**

Bit	Word 4	Word 5	Word 6	Word 7	Word 8	Word 9
0	Bell Running	Bell Overspread Warning	Parameter Read Code	Parameter Read Valve	Actual RPM Value	Actual Flow 1 (Future)
1		Bell Underspread Warning	Parameter Read Code	Parameter Read Valve	Actual RPM Value	Actual Flow 1 (Future)
2	OK to Start	Loss of Feedback Warning	Parameter Read Code	Parameter Read Valve	Actual RPM Value	Actual Flow 1 (Future)
3	Remote Mode	Speed Out of Tolerance Warning	Parameter Read Code	Parameter Read Valve	Actual RPM Value	Actual Flow 1 (Future)
4			Parameter Read Code	Parameter Read Valve	Actual RPM Value	Actual Flow 1 (Future)
5	Atomizer Warning		Parameter Read Code	Parameter Read Valve	Actual RPM Value	Actual Flow 1 (Future)
6	Atomizer Fault	Atomizer Comm Fault	Parameter Read Code	Parameter Read Valve	Actual RPM Value	Actual Flow 1 (Future)
7			Parameter Acknowledge	Parameter Read Valve	Actual RPM Value	Actual Flow 1 (Future)
8	HVC Caused Fault	Bell Overspread Warning	Turbine Drive Valve	Parameter Read Valve	Actual Bearing Air Value	Actual Flow 2 (Future)
9		Bell Underspread Warning	Turbine Drive Valve	Parameter Read Valve	Actual Bearing Air Value	Actual Flow 2 (Future)
10		Loss of Feedback Fault	Turbine Drive Valve	Parameter Read Valve	Actual Bearing Air Value	Actual Flow 2 (Future)
11			Turbine Drive Valve	Parameter Read Valve	Actual Bearing Air Value	Actual Flow 2 (Future)
12		Low Bearing Air Fault	Turbine Drive Valve	Parameter Read Valve	Actual Bearing Air Value	Actual Flow 2 (Future)
13	Not In RUN STATE		Turbine Drive Valve	Parameter Read Valve	Actual Bearing Air Value	Actual Flow 2 (Future)
14	User Input #1		Turbine Drive Valve	Parameter Read Valve	Actual Bearing Air Value	Actual Flow 2 (Future)
15	User Input #2		Turbine Drive Valve	Parameter Read Valve	Actual Bearing Air Value	Actual Flow 2 (Future)

## Output Word 4

### **Bit 0 - Bell Running**

This bit is set when the atomizer control is enabled. It means that the atomizer controller is actively attempting to control the bell speed.

### **Bit 1 - Unused**

### **Bit 2 - OK to Start**

This bit is set when the system determines that the voltage values are in a range where it is allowed to start control. Will remain 0 until the MP2e enters the RUN STATE.

### **Bit 3 - Remote Mode**

This bit is set when the front panel switch is set to remote. When set, an external unit can control the system.

### **Bit 4 - Unused**

### **Bit 5 - Warning**

This bit is set whenever an Atomizer warning is in effect.

### **Bit 6 - Fault**

This bit is set whenever an Atomizer fault is in effect (see "Fault Descriptions" in "Troubleshooting Guide" in the "Maintenance" section).

### **Bits 7 - Unused**

### **Bits 8 - HVC Caused Fault**

This bit indicates that an HVC Fault caused the Atomizer to stop.

### **Bits (9-12) - Unused**

### **Bit 13 - Not in RUN STATE**

MP2e is not in RUN STATE. Provides a positive indication from a BOOTING STATE to the RUN STATE. Allows remote detection of an MP2e being inadvertently left in Local mode after power is cycled.

### **Bits (14 & 15) - User Inputs #1 and #2**

These bits give an integrator the ability to read two discrete inputs, which can be used by their external control system.

## Output Word 5

### **Bit 0 - Bell Overspeed Warning**

This bit is set when the Atomizer detects an overspeed condition as described in the "Automatic Shutdown" section.

### **Bit 1 - Bell Underspeed Warning**

This bit is set when the Atomizer detects an underspeed condition as described in the "Automatic Shutdown" section.

### **Bit 2 - Loss of Feedback Warning**

This bit is set when the Atomizer detects a loss of feedback condition as described in the "Automatic Shutdown" section.

### **Bit 3 - Speed Out of Tolerance Warning**

This bit is set when the Atomizer detects a speed out of tolerance condition as described in the "Automatic Shutdown" section.

### **Bits (4-5) - Unused**

### **Bit 6 - Atomizer Communication Fault**

The system has detected a communication failure after an Ethernet/IP connection was initiated.

### **Bit 7 - Unused**

### **Bit 8 - Bell Overspeed Fault**

This bit is set when the Atomizer faults due to an overspeed condition as described in the "Automatic Shutdown" section.

### **Bit 9 - Bell Underspeed Fault**

This bit is set when the Atomizer faults due to an underspeed condition as described in the "Automatic Shutdown" section.

### **Bit 10 - Loss of Feedback Fault**

This bit is set when the Atomizer faults due to a loss of feedback condition as described in the "Automatic Shutdown" section.

### **Bit 11 - Unused**

### **Bit 12 - Low Bearing Air Fault**

This bit is set when the Atomizer faults due to a low bearing air pressure condition as described in the "Automatic Shutdown" section.

### **Bit (13 -15) Unused**

## Output Word 6

### **Bits (0-6) - Parameter Read Code**

This 7 bit value tells the system which parameter is being displayed.

### **Bit 7 - Parameter Acknowledge**

When this bit changes from cleared to set a new Parameter Value is being displayed. It is cleared when the Parameter Read Strobe and Parameter Write Strobe are both cleared.

**Bits (8-15) - Turbine Drive Value**

This byte (8 bit) value displays the air pressure applied to the Atomizer turbine. If this value is monitored for each speed and paint combination, it can be used as an indicator of correct operation or a potential problem.

**Output Word 7**

**Bits (0-15) - Parameter Read Value**

This 16 bit value tells the system which parameter is being displayed.

**Output Word 8**

**Bits (0-7) - Actual RPM Value**

The byte (8 bit) value displays the latest turbine speed in 1000 RPM.

**Bits (8-15) - Actual Bearing Air Value**

This byte (8 bit) value displays the latest bearing air pressure reading.

**Output Word 9**

**Bits (0-7) - Actual Flow #1 Value**

In the future this byte (8 bit) value will be used to display the latest measurement of flow rate #1.

**Bits (8-15) - Actual Flow #2 Value**

In the future this byte (8 bit) value will be used to display the latest measurement of flow rate #2.

**Parameter Select Codes**

**Parameter Select = 1: Atom Enabled**

READ — returns value 0=Disabled  
1= Enabled  
WRITE — is not supported

**Parameter Select = 2: Atom Type**

READ — returns value  
0= RMA300-500  
1= AeroBell  
2= AeroBell33  
3= RMA100-200  
4= TurboDisk  
5= Auto Gun  
6= RMA303-SBA  
7= RMA550

WRITE — is not supported.

**Parameter Select = 3: Input Mode**

READ — returns bit values of 0-127  
WRITE — sets bit values of 0-127  
See Table 13 for bit details  
See table for corresponding jumpers

TABLE 15	
Bit	Analog Input
0	1) Bearing Air Feedback
1	2) Bell Speed Setpoint
2	3) Paint Flow Rate 1 Setpoint
3	4) Paint Flow Rate 2 Setpoint
4	5) Shaping Air 1 Setpoint
5	6) Shaping Air 2 Setpoint
7	7) (unassigned)

A "0" bit = Voltage Mode (0-10V)  
A "1" bit = Current Mode (4-20mA)

**Parameter Select = 4: Min Bearing Air**

READ — returns value 0—100  
WRITE — is not supported

**Parameter Select = 5: Unilink Mode**

READ — returns value 0 = Disabled  
1 = Enabled  
WRITE — is not supported

**Parameter Select = 6: Unilink Gun Sel**

READ — returns value 0 = Bell  
1 = Gun  
WRITE — sets value 0 = Bell  
1 = Gun

**Hardware Signals**

TABLE 16		
J14	Analog Inputs	V-I Select Jumper
J14-1	1—Bearing Air Feedback	JMP15
J14-3	2—Bell Speed Setpoint	JMP14
J14-5	3—Paint Flow Rate 1 Setpoint	JMP13
J14-7	4—Paint Flow Rate 2 Setpoint	JMP12
J14-9	5—Shaping Air 1 Setpoint	JMP11
J14-11	6—Shaping Air 2 Setpoint	JMP10
J14-13	7—(unassigned)	JMP9
even pins	Ground	

Analog Input Jumper setting:  
Pins 1-2 = Voltage Mode (0-10V)  
Pins 2-3 = Current Mode (4-20mA)

**TABLE 17**

Bit	Digital Input
J5-1	1—Bell Spin Enable
J5-3	2—Paint Trigger 1
J5-5	3—Paint Trigger 2
J5-7	4—Dump 1
J5-9	5—Dump 2
J5-11	6—Fluid Override 1
J5-13	7—Fluid Override 2
J5-15	8—Bell Cup Wash
J5-17	9—(unassigned)
J5-19	10—Unilink Gun Select
J5-21	11—User Input #1
J5-23	12—User Input #2
J5-2, 4, 6, 8, 10, 12, 14, 16, 18, 20, 22, 24	Ground

**NOTE**

- Digital Input 10 (Unilink Gun Select) is only active when Unilink Mode is enabled and the Ethernet/IP interface is disabled.

**TABLE 18**

J4	Analog Outputs	V-I Select Jumper
J4-1	1—Bell Drive	JMP1
J4-3	2—Bell Speed Read Out	JMP2
J4-5	3—Paint Flow Rate 1	JMP3
J4-7	4—Paint Flow Rate 2	JMP4
J4-9	5—Shaping Air 1	JMP5
J4-11	6—Shaping Air 2	JMP5
J4-13	7—(future)	JMP7
J4-15	8—(future)	JMP8
even pins	Ground	
J4-17, J4-18	(N.C.)	

Analog Output Jumper setting:  
 Pins 1-2 = Voltage Mode (0-10V)  
 Pins 2-3 = Current Mode (4-20mA)

**NOTE**

- Current mode output requires the installation of an optional 4-20mA converter: Ransburg part number A13248-00.
- Location of the jumpers and I/O connectors referred to in tables 16, 17, 18 & 19 can be found in Figure 56 in the Appendix.

**TABLE 19**

J1	Digital Output
J1-1	1—Brake
J1-3	2—Paint Trigger 1
J1-5	3—Paint Trigger 2
J1-7	4—Dump 1
J1-9	5—Dump 2
J1-11	6—Fluid Override 1
J1-13	7—Fluid Override 2
J1-15	8—Bell Cup Wash
J1-17	9—Overspeed Warning/Fault
J1-19	10—Underspeed Warning/Fault
J1-21	11—Loss of Bell Feed Back Warning/Fault
J1-23	12—Low Bearing Air Warning/Fault
J1-25	13—Speed Out of Tolerance Warning
J1-27	14—(unassigned)
J1-29	15—(unassigned)
J1-31	16—HV On
J1-33	17—User Output #1
J1-35	18—User Output #2
J1-2, 4, 6, 8, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36	Ground

**NOTE**

- Digital Outputs 9 to 13 (Atomizer Fault signals) are only active when Ethernet/IP is disabled, i.e. when operating in Discrete mode.



# Ransburg Discrete IO Controller





# Discrete IO Controller - INTRODUCTION

## DISCRETE IO CONTROLLER GENERAL DESCRIPTION

The Discrete IO Controller, for use with the MicroPak 2e Controller, is designed to provide a universal I/O interface for high voltage controller functions. It is intended to be used in installations which do not support the standard MicroPak 2e Ethernet/IP control interface.

### NOTE

- When the Discrete IO option is ordered and enabled by the factory, this indicates the user intends to use physically wired I/O signals to control the system. Therefore the software will disable the ability for the user to enable the Ethernet IP functionality.




Figure 54: MicroPak 2e Multi I/O Board

## SPECIFICATIONS (At Sea-Level Conditions)

### Environmental/Physical

<b>Operating Temperature:</b>	0°C to +55°C
<b>Storage &amp; Shipping Temp.:</b>	-40°C to +85°C
<b>Humidity:</b>	95% Non-Condensing
<b>Physical Size:</b>	2" tall X 7.5" X 4.75" (5.1cm x 19.1 x 12.1cm)
<b>Mounting:</b>	Figure 48 in Appendix

### Environmental Requirements

#### Power Required:

**J15 - Controller :** 24V DC @ 0.25 Amps

**Note:** 24V DC power supply must be regulated and have over current and over voltage protection.

### Electrical - Communication Requirements

**Control and Reporting:** Ethernet to the MicroPak 2e, port J8 or J9

**Note:** A unique MAC address is hard coded into each Discrete IO Controller.

*(Continued on next page)*

## SPECIFICATIONS (At Sea-Level Conditions)

### Electrical - Controls in Local Mode

<b>Analog In:</b>	(0-10V or 4-20mA) (None Active)
<b>Analog Out:</b>	(0-10V or 4-20mA with option) HV Output Level, Current Output Level
<b>Discrete In:</b>	(0-24V) (None Active)
<b>Discrete Out:</b>	(0-24V, Current Sourcing) HV Ready, HV On, Current Fault, dx/dt Fault, V/I Feedback Fault, Local, Alarm Out, Interlock Fault

**NOTE:** In Local Mode, the functions of the Analog and Discrete input signals are performed by the Front Panel user interface.

### Electrical - Controls in Remote Discrete Mode

<b>Analog In:</b>	(0-10V or 4-20mA), HV Setpoint, Over Current Setpoint, dx/dt Sensitivity
<b>Analog Out:</b>	(0-10V or 4-20mA with option), HV Output Level, Current Output Level
<b>Discrete In:</b>	(0-24V), HV Enable (On), HV Disable (Off) / Fault Reset, dx/dt Disable, Part in position, HV On (Latching)
<b>Discrete Out:</b>	(0-24V, Current Sourcing), HV Ready, HV On, Current Fault, dx/dt Fault, V/I Feedback Fault, Local, Alarm Out, Interlock Fault

## CONFIGURATION PARAMETERS AND SETTINGS

**TABLE 20**

Parameter	Password Level
DISCRETE MIO Settings	
Disc Analog Inputs	System
Discrete MIO	Config

# Discrete IO Controller - OPERATION

The Discrete IO Controller supports two operating modes.

## Remote Discrete Control

Remote control mode is activated when the front panel Local/Remote switch is set to the Remote position. In this mode, the Discrete IO controller's inputs are used to control the operation of the HV controller.

## Local Front Panel Control

This mode is activated whenever the front panel Local/Remote switch of the MicroPak 2e Controller is set to Local. In this mode, the MicroPak 2e HV controller is operated from the front panel controls.

## Control Input Scaling

The scaling of the analog control inputs is determined by the configuration of the MP2e.

## Analog Inputs in Voltage Control Mode

High Voltage Setpoint: 0-100 KV  
 OverCurrent Setpoint: 0-1000  $\mu$ A (RP1000)  
 0-250  $\mu$ A (nonRP1000)  
 di/dt Sensitivity: 0-60  $\mu$ A/100 msec

## Analog Outputs

HV Output Level: 0-100 KV  
 Current Output Level: 0-1000  $\mu$ A (RP1000)  
 0-250  $\mu$ A (nonRP1000)

## Hardware Signals

**TABLE 21**

J14	Analog Inputs	V-I Select Jumper
J14-1	1 — High Voltage Setpoint	JMP15
J14-3	2 — Over Current Setpoint	JMP14
J14-5	3 — dx/dt sensitivity percentage, 0% (insensitive) to 100% (very sensitive)	JMP13
J14-7	4 — Unassigned)	JMP12
J14-9	5 — Unassigned)	JMP11
J14-11	6 — Unassigned)	JMP10
J14-13	7 — unassigned)	JMP9
even pins	Ground	

Analog Input Jumper setting:  
 Pins 1-2 = Voltage Mode (0-10V)  
 Pins 2-3 = Current Mode (4-20mA)

**TABLE 22**

J5	Digital Inputs
J5-1	1 — HV Enable (On)
J5-3	2 — HV Disable (Off)
J5-5	3 — dx/dt Disable pulled high == enabled
J5-7	4 — Part in Position (Future)
J5-9	5 — HV On (Latching)
J5-11	6 — (Unassigned)
J5-13	7 — (Unassigned)
J5-15	8 — (Unassigned)
J5-17	9 — (unassigned)
J5-19	10 — (Unassigned)
J5-21	11 — (Unassigned)
J5-23	12 — (Unassigned)
J5-2, 4, 6, 8, 10, 12, 14, 16, 18, 20, 22, 24	Ground

## DISCRETE I/O CONTROLLER LOGIC RELATING TO INPUTS ON CONNECTOR J5

(Refer to signals in Table 22)

### Priority of inputs affecting the enabling of HV output

Starting with software version V1.1.03, the Discrete I/O controller software has been modified to include logic to prioritize these input signals.

- Front panel switch for local/remote has highest priority
  - Changing the state of the switch will :
    - Disable HV\_Output\_Enabled (if active)
    - NOT affect any interlock faults
    - Change which reset input signals are enabled for clearing faults (local or remote)
- In “Remote Mode” (with Ethernet/IP disabled and DIO present and enabled):
  - HV\_Disable (DIO.J5-3) has next highest priority. While active it will:
    - Override any interlock faults and put system into STPD mode
      - Interlock faults will automatically retrigger if still asserted when HV\_Disable clears
  - Override the HV\_On signal enabling of HV\_Output\_Enabled and put system into STPD mode
    - HV\_ON will NOT automatically retrigger
  - Reset/Override HV\_On\_Latching enabling of HV\_Output\_Enabled and put system into STPD mode
    - HV\_On\_Latching will NOT automatically retrigger
- Interlock input signals (see HV Controller) have the next highest priority. When active they will:
  - Override the HV\_On signal enabling of HV\_Output\_Enabled and put system in FALT mode
    - HV\_ON will NOT automatically retrigger
  - Reset/Override HV\_On\_Latching enabling of HV\_Output\_Enabled and put system in FALT mode
    - HV\_On\_Latching will NOT automatically retrigger
- HV\_On (DIO.J5-1) has the next highest priority.
  - On its rising edge going active, it will enable HV\_Output\_Enabled and put system in RUN mode
  - On its falling edge going inactive, it will disable HV\_Output\_Enabled and put system in STPD mode
- HV\_On\_Latching (DIO.J5-9) has the lowest priority.
  - On its rising edge going active, it will enable HV\_Output\_Enabled and put system in RUN mode.
  - This signal will have no further affect until the next rising edge transition.

TABLE 23		
J4	Analog Outputs	V-I Select Jumper
J4-1	1—HV Output Level	JMP1
J4-3	2—(Unassigned)	JMP2
J4-5	3—(Unassigned)	JMP3
J4-7	4—Current Output Level	JMP4
J4-9	5—(Unassigned)	JMP5
J4-11	6—(Unassigned)	JMP5
J4-13	7—(Unassigned)	JMP7
J4-15	8—(Unassigned)	JMP8
even pins	Ground	
J4-17, J4-18	(N.C.)	

Analog Output Jumper setting:  
 Pins 1-2 = Voltage Mode (0-10V)  
 Pins 2-3 = Current Mode (4-20mA)

**NOTE**

- Current mode output requires the installation of an optional 4-20 mA converter: Ransburg part number A13248-00.
- Location of the jumpers and I/O connectors referred to in tables 21, 22, 23 & 24 can be found in Figure 56 in the Appendix.

TABLE 24	
J1	Digital Output
J1-1	1—HV Ready
J1-3	2—HV On
J1-5	3—Current Fault
J1-7	4—dx/dt Fault
J1-9	5—V/I Feedback Fault
J1-11	6—Local
J1-13	7—Alarm Out
J1-15	8—Interlock Fault
J1-17	9—(Unassigned)
J1-19	10—(Unassigned)
J1-21	11—(Unassigned)
J1-23	12—(Unassigned)
J1-25	13—(Unassigned)
J1-27	14—(unassigned)
J1-29	15—(unassigned)
J1-31	16—(Unassigned)
J1-33	17—(Unassigned)
J1-35	18—(Unassigned)
Even Pins	Ground

# MicroPak 2e Controls - INTEGRATION NOTES

## GUIDELINES

### Controller DIP Switch Settings

Each of the MP2e boards have DIP switches. These are configured at the factory and should be left as received. The following information is included to support servicing.

Both the High Voltage Control Processor and the Display and Communications Processor boards have a 2 position dip switch labeled S1. Switch 1 is not currently used and switch 2 which is for factory use only, should remain in the CLOSED position for normal operation.

Likewise, the MicroPak 2e Multifunction I/O Boards (Atomizer and Discrete IO Controllers) contain a 6 position dip switch labeled S1. The first four switch positions are used to determine the I/O function of the Multi I/O Board. For the Atomizer board, switches 1, 3 & 4 must be CLOSED and switch 2 must be OPEN. For the Discrete IO board, switches 1, 2 & 3 must be CLOSED and switch 4 must be OPEN. On both boards, switch 5 is not currently used and switch 6, which is for factory use only, should remain in the CLOSED position for normal operation.

### Connecting MIO / DIO Controllers

When an Atomizer Controller or a Discrete IO Controller is used with a MicroPak2e, the Controller's Multi-Function IO Board(s) must be connected to the MP2e HVCP board via Cat 5 Ethernet cabling. When a single add-on controller is present, the cable should run from J8 or J9 of the add-on controller to J17 or J18 of the MP2e HVCP Controller board. When more than one add-on controller is used, the second and subsequent controllers should be connected to the remaining open port (J8 or J9) of the preceding controller. This use of a daisy chain connection is acceptable, since all the MicroPak 2e boards use a 3 port Ethernet Switch to implement external Ethernet connections.

### Discrete IO Characteristics

Both the MP2e Interlock Inputs and the MIO Discrete Inputs are implemented as a resistor divider followed by a filter capacitor, feeding into a Schmidt trigger. This input configuration requires that the applied input voltage (0-24V) is referenced to the 24V ground of the controller.

The MIO Discrete Outputs are implemented using IC drivers which source current from the 24VDC controller power. The current draw on these outputs should not exceed 250 mA.

### Atomizer Operation

When deciding how to control an atomizer, there are several important issues to consider.

1. The atomizer must not be run without an adequate supply of bearing air.
2. The flow of paint must be interlocked with the atomizer's rotation. That is, paint must not flow if the atomizer is not rotating. Failure to stop the flow of paint will result in "flooding" which can destroy an atomizer.
3. The flow of paint must be interlocked with the fault state of the HV controller. That is, paint must not flow if the HV controller is faulted. Failure to observe this could increase the risk of fires.
4. The flow of solvent must be interlocked with the atomizer's rotation and also with the high voltage control.

Compliance with item 1 is built into the Atomizer Controller and requires user action to defeat. The user is responsible for the effects of defeating this operational interlock.

Compliance with items 2 and 3 is easily achieved by using the Paint Trigger outputs of the Atomizer Controller. The controller has been programmed to interlock these outputs with the atomizer's rotation and the lack of a HV controller fault, thereby freeing the user from adding additional control logic to meet these requirements. This behavior is included in all input modes.

Compliance with item 4 is also easily achieved by using the Wash output (Bell Cup/Disk/Gun) of the Atomizer Controller. The controller has been programmed to interlock this output with the high voltage controller, so that if high voltage controller is enabled, the Bell Cup Wash output will not activate. This will prevent solvent from being dispensed when high voltage is present.

**⚠ CAUTION**

- Failure to interlock the flow of paint with atomizer rotation may cause damage to the atomizer.

### Atomizer Interlock Behavior

To help implement a safer paint booth, the High Voltage controller has been programmed to provide the state of the interlocks to the Atomizer controller with each update packet. This enables the Atomizer Controller to perform a forced stop, using the air brake, if an interlock opens while the atomizer is in motion. In addition, the atomizer controller will also immediately disable the paint and solvent outputs.

### Atomizer - MP2e Power Cycling

When the MP2e power is cycled quickly using the front panel switch (i.e. OFF for less than 3 seconds), an Atomizer fault may occur. This is because the Atomizer Controller executes a reboot operation every time a failure of the RansNet communications link is detected. This behavior ensures the Atomizer Controller always has current configuration data from the MP2e.

### Ethernet/IP Networking

It is important to use a suitably configured network for Ethernet/IP communications. Ransburg's recommendations follow:

- Use a private switched LAN for an Ethernet/IP control network.
- For large installations the use of a switch which supports IGMP Snooping is recommended. These switches can direct multicast traffic to only the multicast group members instead of broadcasting it to all connected ports.
- Do not allow Internet access from the Ethernet/IP control network.

**NOTE**

- The MicroPak 2e does not support multicast communications.
- Many PLCs and robots make use of multicast communications to minimize packet transmissions. Low cost Ethernet switches treat these as broadcasts and send these messages to all connected devices. This can present a substantial processing load for devices which are not group members.

- Monitor the Ethernet/IP control network to confirm it remains isolated.
- If remote monitoring from the plant LAN is necessary, use a managed gateway to limit access to the private LAN.

For further guidance refer to ODVA document: *Network Infrastructure for Ethernet/IP™*, Publication Number: PUB00035R0.

### Ethernet/IP TCP Configuration

The present implementation of TCP Configuration through Ethernet/IP, requires that the MicroPak 2e does not have another active Ethernet/IP connection when the TCP Configuration message exchange occurs. This means that if a PC is being used to set the TCP configuration, there must not be a PLC or robot link to the MicroPak 2e (i.e. the Fault Menu Screen must show "eip" in lower case).

### Ethernet/IP Monitoring of MP2e Faults

When programming the controlling PLC to detect faults the user should always:

- Use bit 6 of output word zero to detect a Voltage Controller fault.
- Use bit 6 of output word four to detect an Atomizer Controller fault.

The bits contained in output words zero, one, four and five are provided to aid fault isolation. These bits should not be relied on for fault detection, since it is not guaranteed that a fault will always set an isolating bit.

### Sending Ethernet/IP Remote Commands

Sending commands to the MP2e while it is starting up and has not yet entered RUN STATE should be avoided as it may result in unexpected behavior.

Starting with V1.1.02, any incoming Ethernet/IP commands will be ignored until the MP2e has entered RUN STATE. The MP2e now provides Ethernet/IP Outputs (Word 0, Bit 13 and Word 4, Bit 13) which will be set ("1") when the MP2e is not in RUN STATE.



## HIGH VOLTAGE CONTROLLER LOGIC RELATING TO INPUTS ON CONNECTOR J5

### (Interlocks and Remote signals)

Starting with software version V1.1.07, the High Voltage Controller software has been modified to include logic to prioritize these input signals.

### Input signals on HVC Connector J5 (Table 5)

- J5-7/8 (+/-) Door Interlock
  - CAN BE disabled (Ignored)
- J5-9/10 (+/-) Booth Air Interlock / HV\_Reset
  - CAN BE disabled (Ignored)
  - CAN BE configured as Booth Air Interlock
  - CAN BE configured as HV\_Reset signal
    - NOT available if Ethernet/IP enabled
    - NOT available if DIO enabled
    - Only active in REMOTE operation
    - Only means to Clear Faults in REMOTE operation
- J5-11/12 (+/-) Misc Interlock / Trigger (HV\_On)
  - CAN BE disabled (Ignored)
  - CAN BE configured as Misc. Interlock
  - CAN BE configured as Trigger (HV\_On) signal
    - NOT available if Ethernet/IP enabled
    - NOT available if DIO enabled
    - Only active in REMOTE operation
    - Requires use of KV\_Setpoint input signal for setting KV output level (no input signal will result in a KV Setpoint of 0KV)
- J5-13/14 (+/-) Remote Stop
  - ALWAYS active
- J5-15/16 (+/Gnd) KV Setpoint
  - NOT available if Ethernet/IP enabled
  - NOT available if DIO enabled
  - Only active in REMOTE operation

### NOTE

- Currently there is NO standard SBC configuration which routes this signal pair outside of the SBC enclosure.
- Currently there are 4 pairs of unassigned pins on the SBC Interlock connector.

### Priority of inputs affecting the enabling of HV output

- Front panel switch for local/remote has highest priority
  - Changing the state of the switch will :
    - Disable HV\_Output\_Enabled (if active)
    - NOT affect any interlock faults
    - Change which reset input signals are enabled for clearing faults (local or remote)
- In “Remote Mode” (with Ethernet/IP and DIO disabled):
  - Any enabled and active Interlocks have next highest priority
    - HV\_Reset (HVC.J5-9) is ignored
    - HV\_On\_Trigger (HVC.J5-11) is ignored
    - System is in FALT mode
    - HV\_Output is Off
- HV\_Reset (HVC.J5-9) has the next highest priority
  - While active it will:
    - Override the HV\_On\_Trigger signal enabling of HV\_Output\_Enabled and put system into STPD mode
    - HV\_On\_Trigger will NOT automatically retrigger
- HV\_On\_Trigger (HVC.J5-11) has the lowest priority
  - On its rising edge going active, it will enable HV\_Output\_Enabled and puts system in RUN mode
  - On its falling edge going inactive, HV\_Output\_Enabled will remain active until HV\_Reset becomes active

# MAINTENANCE

## WARNING

► Before troubleshooting gun and control unit problems, flush the gun with solvent and purge with air. Some of the tests will require high voltage to be applied to the gun, so the gun must be empty of paint and solvent.

## TROUBLESHOOTING GUIDE

Fault	Description	Solution
<b>Cable Fault (CF)</b>	The Cable Fault indicates the control unit does not detect a high voltage section on the end of the cable. The fault typically occurs at a high voltage trigger.	<ol style="list-style-type: none"> <li>1. Check for loose wiring between the pc board connector and the high voltage section by pulling on each wire. Repair if necessary. Ensure both connectors are secure and re-test for CF fault.</li> <li>2. Replace high voltage section or send unit in for repair.</li> <li>3. Send unit in for repair.</li> <li>4. Low Voltage cable interface, poor or no connection.</li> <li>5. No Low Voltage cable.</li> </ol>

## NOTE

► When the system is configured as “CabinetType = ControlPak”, there is a front panel menu option for “FluidInterlock”. When “FluidInterlock” is set to “Disabled”, that will turn off Atomizer checking for faults and warnings.

## TROUBLESHOOTING GUIDE - Fault / Warn

General Problem	Fault Report	Explanation
<b>Atom Faults</b>	No Fault	No Fault was detected.
	Bell Overspeed	The bell speed feedback indicated the bell exceeded the setpoint. *
	Bell Underspeed	The bell speed feedback indicated the bell was below the setpoint. *
	Loss of Feedback	The fiber optic speed feedback signal was not detected. *
	Low Bearing Air	The bearing air monitor indicated the pressure was too low. *
	RansNet CommLost	The Ethernet communications between the HVC and speed controller were interrupted.
	Faulted by HVC	The speed controller has been stopped due to an HVC fault.
	Interlock	The Atomizer controller has detected an open interlock. *
<b>Atom Warns</b>	Speed Out of Tol	Speed is not within +/- 5% of setpoint. *

\* For further information, see “Automatic Shutdown” in the section of this manual on Operation of the Atomizer.

(Continued On Next Page)

**TROUBLESHOOTING GUIDE - Fault / Warn (Cont.)**

General Problem	Fault Report	Explanation
<b>HVC Faults</b>	No Fault	No Fault was detected.
	Over Current	The current value has exceeded the I Limit Hi or the Max System Limit.
	MAX KV	The system has raised the Variable Voltage Output to the system maximum, but could not reach the setpoint.
	Min Output	The system has lowered the Variable Voltage Output to zero and still is above the setpoint.
	kV Limit	The system has exceeded the kV Limit Hi or the Max System Limit.
	DVDT	The system has detected a dv/dt event.
	DIDT	The system has detected a di/dt event.
	Cascade Feedback	The current or voltage feedback from the cascade is out of range.
	Voltage Cable	The system has detected a loss of the High Voltage Feedback signal from a Consolidated cascade.
	Current Cable	The system has detected a loss of the Current Feedback signal from a Consolidated cascade.
	KV Low	The system has fallen below kV Lo Limit while operating in Current Mode.
	Communications	The system has detected an Ethernet/IP communication failure. Possible causes are: <ul style="list-style-type: none"> <li>• Receipt of a reset command when no fault was active.</li> <li>• Receipt of an invalid high voltage controller parameter value.</li> <li>• Receipt of an invalid atomizer parameter value, Atomizer Fault LED will also be lit</li> </ul>
	FLT'd by Atom	An atomizer fault has caused the high voltage controller to stop.
	Comm Timeout	Either the MP2e or the "originating" Ethernet/IP controller failed to receive a message for three update intervals, so the connection was dropped.
	System Mode	The control software detected an invalid state.
	Interlock	One of the enabled interlock input circuits was broken, i.e. the circuit was opened.
	Remote Stop	The Remote Stop input circuit was opened.
	HVC WDog Reset	The high voltage control processor board was reset by the WatchDog Timer.
DSP WDog Reset	The display processor board was reset by the WatchDog Timer.	
HV Power Off	External power was removed from the cascade power input—J4.	
<b>HVC Warns</b>	Over Current	The current level is within 10% of Max $\mu$ A Limit.
	Over Voltage	The voltage level is within 10% of KV High Limit (current mode only).
	Under Voltage	The voltage level is within 10% of KV Low Limit (current mode only).
	Max Output	Vct is maximum and the kV setpoint has not been reached.
	KV High Limit	The voltage level (kV) is within 10% of kV Maximum, i.e. 110 kV.

# PARTS IDENTIFICATION

## MICROPAK 2e HIGH VOLTAGE CONTROLLER - PARTS LIST

Part No.	Description
A13338-XXXXXXXX	MicroPak 2e HV & Atomizer Controller For replacement use, the user should order the same model number (-XXXXXXXX) listed on the original invoice.
A13245-X1	MicroPak 2e Multi-Function Board, "X" indicates quantity of A13248-00 boards included
A13248-00	MicroPak 2e Analog Output, 4-20mA add-on board
A11111-00	Volume Booster, 1:1
78643-00	E/P Transducer, High Speed, High Flow, DIN Rail Mount, 0-10V : 0-100PSI
A11485-01	Pneumatic Solenoid, minimum 4mm bore, 0-120 PSI
A13596	Pressure Transducer, 0-100 PSI : 0-10V
A13245-X8	MicroPak 2e Multi-Function Board, Discrete I/O configuration. "X" indicates quantity of A13248-00 boards included.

\* **NOTE:** All nozzles available in kits of 3.

# APPENDIX




Figure 55: MicroPak 2e Controller Panel Mount Layout




Figure 56: MicroPak 2e Controller/Multi-Function IO Layout



## INITIALIZATION SCREENS

On receipt from the factory, all MP2e units delivered with Software Version 1.1.00 and above will display the following 11 initialization screens. These screens must be stepped through and the requested parameters set before the MP2e will operate.

If the user is unfamiliar with operation of the MP2e front panel, it is suggested he read the section titled MENUS AND OPERATIONS before proceeding with the following initialization steps.

Figure 57, shown below, informs the user that the Initialization sequence is active and the SCREEN pushbutton should be used to advance through the screens shown on the right hand ATOMIZER display. Figures 58-67 will display a flashing S in the lower right corner to indicate the user has System privilege and that the ATOMIZER screen menu is active.




Figure 57: Init Menu Screen 1 (Left)




Figure 58: Init Menu Screen 2 (Right)




Figure 59: Init Menu Screen 3 (Right)




Figure 60: Init Menu Screen 4 (Right)

Figures 59 - 60 above, inform the user of the need to set application specific values for three parameters which help assure safe operation.




Figure 61: Init Menu Screen 5 (Right)

Figure 61 above, requires the user to set the Over Current Limit. This is done as follows:

- Press SET to change the →value←.
- Press Rt ARROW to 'select' →Digit←.
- Press SET to begin digit by digit entry.
- Use Up/Dn ARROWS followed by SET to enter the new value, one digit at a time.
- Press Rt ARROW to 'select' →Save←.
- Press SET to return to the menu of Fig 61.





Figure 62: Init Menu Screen 6 (Right)




Figure 63: Init Menu Screen 7 (Right)




Figure 64: Init Menu Screen 8 (Right)




Figure 65: Init Menu Screen 9 (Right)

Figures 62 - 65 above, inform the user of the need to set application specific values for Di/Dt operation.




Figure 66: Init Menu Screen 10 (Right)

Figure 66 above, allows the user to set the Di/Dt Mode and Di/Dt Sensitivity. The factory default setting enables Di/Dt at the maximum sensitivity (0). If the users application allows using Di/Dt, the Mode can be left as is and only the sensitivity changed. Di/Dt Sensitivity can be changed as follows:

- Press *Rt* ARROW to 'select' →00←.
- Press SET to change the →00←.
- Press *Rt* ARROW to 'select' →Digi←.
- Press SET to begin digit by digit entry.
- Use *Up/Dn* ARROWS followed by SET to enter the new value, one digit at a time.
- Press *Rt* ARROW to 'select' →Save←.
- Press SET to return to the menu of Fig 66.
- Press SCREEN to advance to Fig 67.





Figure 67: Init Menu Screen 11 (Right)

Figure 67 above, informs the user they will next enter the Configuration Menus described in the Operations section of this manual.

# MANUAL CHANGE SUMMARY

## LN-9624-00-R3 - Replaces LN-9624-00.2 with the following changes:

No.	Change Description	Page(s)
1.	Update manual to new design	All Pages
2.	Format Manual to show three controllers; HV, Atomizer, and Discrete I/O	All Pages
3.	Update "SPECIFICATIONS"	12-13
4.	Change the range on the second screen (Figure 3), update figure numbers and add "User Password Menu" from pg 27	13
5.	Insert "Software Mismatch Fault" section	23
6.	Insert NOTE after figure 14b.	24
7.	Add "Software Version Menu" text between figures 23 and 24 and update figure numbers	26
8.	Move "Atomizer Shape Air Menu" to pg 49, "Atomizer Fluid Maintenance Menu" to pg 50 and update figure numbers	27
9.	Change figure 29 to figure 28	28
10.	Delete "Remote Option Configuration Settings" section and update figure numbers	29
11.	Update figure numbers	30-31
12.	Update figure numbers	33
13.	Update figure numbers and realign arrows in the screens	34-35
14.	Replace text in second "NOTE" and add TABLE 6 with "DIAGNOSTICS MENU" section from page 31	32
15.	Add new "NOTE"	36
16.	Update copy for Bits 9 and 10	41
17.	Update figure number	44-48
18.	Update figure numbers and add "Atomizer Shape Air Menu" text from page 27	49
19.	Update figure numbers and add "Atomizer Fluid Maintenance Menu" text from page 27	50
20.	Update figure number to 54	59
21.	Correct spacing and add line to Parameter Select = 2	56
22.	Add title "CONFIGURATION PARAMETERS AND SETTINGS" and renumber table number to 20	60
23.	Update copy for both tables 21 and 22	61
24.	Add "High Voltage Controller Logic" section	65
25.	Update figure numbers	69-72

## WARRANTY POLICY

This product is covered by Carlisle Fluid Technologies materials and workmanship limited warranty. The use of any parts or accessories, from a source other than Carlisle Fluid Technologies, will void all warranties. For specific warranty information please contact Carlisle Fluid Technologies.

Carlisle Fluid Technologies is a global leader in innovative finishing technologies. Carlisle Fluid Technologies reserves the right to modify equipment specifications without prior notice.

DeVilbiss®, Ransburg®, MS®, BGK®, and Binks®,  
are registered trademarks of Carlisle Fluid Technologies, Inc.

©2018 Carlisle Fluid Technologies, Inc.  
All rights reserved.

For technical assistance or to locate an authorized distributor, contact one of our international sales and customer support locations.

<b>Region</b>	<b>Industrial / Automotive</b>	<b>Automotive Refinishing</b>
<b>Americas</b>	Tel: 1-800-992-4657 Fax: 1-888-246-5732	Tel: 1-800-445-3988 Fax: 1-800-445-6643
<b>Europe, Africa Middle East, India</b>	Tel: +44 (0)1202 571 111 Fax: +44 (0)1202 573 488	
<b>China</b>	Tel: +8621-3373 0108 Fax: +8621-3373 0308	
<b>Japan</b>	Tel: +81 45 785 6421 Fax: +81 45 785 6517	
<b>Australia</b>	Tel: +61 (0) 2 8525 7555 Fax: +61 (0) 2 8525 7575	

For the latest information about our products, visit [www.carlisleft.com](http://www.carlisleft.com).